

FabiaTech Corporation

IPC Solution

Website: <http://www.FabiaTech.com>

Email: support@FabiaTech.com

Small Cube System
Fanless Series
FX5405 User's Manual

APR 2009
Version: 1.1
Part Number: FX5405

Copyright

Copyright © 2008 FabiaTech Corporation, The content of this publication may not be reproduced in any part or as a whole, transcribed, stored in a retrieval system, translated into any language, or transcribed in any form or by any means, electronic, mechanical, and magnetic... or otherwise without the prior written permission of FabiaTech Corporation.

Disclaimer

FabiaTech makes no representation of warranties with respect to the contents of this publication. In an effort to continuously improve the product and add features, FabiaTech reserves the right to revise the publication or change specifications contained in it from time to time without prior notice of any kind from time to time.

FabiaTech shall not be reliable for technical or editorial errors or omissions, which may occur in this document. FabiaTech shall not be reliable for any indirect, special, incidental or consequential damages resulting from the furnishing, performance, or use of this document.

Trademarks

Trademarks, brand names and products names mentioned in this publication are used for identification purpose only and are the properties of their respective owners.

Technical Support

If you have problems or difficulties in using the system or setting up the relevant devices, and software that are not explained in this manual, please contact our service engineer for service, or send email to support@FabiaTech.com.

Returning Your Board For Service & Technical Support

If your board requires servicing, contact the dealer from whom you purchased the product for service information. You can help assure efficient servicing of your product by following these guidelines:

- ❑ A list of your name, address, telephone, facsimile number, or email address where you may be reached during the day
- ❑ Description of you peripheral attachments
- ❑ Description of your software (operating system, version, application software, etc.) and BIOS configuration
- ❑ Description of the symptoms (Extract wording any message)

For updated BIOS, drivers, manuals, or product information, please visit us at www.FabiaTech.com

Table of Contents

FX5405 User's Manual	i
Chapter 1 Introducing the FX5405 System	1
Overview.....	1
Series Comparison Table	2
Layout.....	3
Specifications.....	4
Packing List	5
Chapter 2 Hardware Installation	7
Before Installation	7
Removing Covers –Installing Hardware.....	8
LED Indicators (On the Front Panel)	13
Connecting the Monitor, Keyboard and Mouse	13
Connecting the COM port.....	14
Connecting the CANBUS port	14
Connecting the L1/L2 LAN ports and USB Ports	15
Connecting the Audio Microphone In/ Speak Out	15
Connecting the DC Power and Power Button	16
Jumper Setting	17
Chapter 3 BIOS Setup	19
Overview.....	19
BIOS Functions	20
Keyboard Convention	21
Main Setup	22
Advanced Setup.....	23
CPU Configuration.....	23
IDE Configuration.....	23
SuperIO Chipset - Configuration WIN627 Super IO Chipset	26
Hardware Health Configuration.....	27
Advanced ACPI Settings	28
USB Configuration	29
PCIPnP Setup.....	31

Boot Setup	34
Boot Setting Configuration	35
Boot Device	37
Hard Disk Drives	38
Security setup	39
Chipset Setup	41
Northbridge Configuration	41
Southbridge Configuration	42
POWER MANAGEMENT	44
Power Management/APM	44
Chapter 4 Software Installation	47
System Driver	47
WIN 98/2000/XP Driver	47
VGA Driver for WIN98SE/ME/2000/XP/NT4.0	48
Audio Drivers	48
WIN 98/2000/XP Driver	48
USB 2.0 Driver	49
WIN 98 Driver	49
LAN Utility & Driver (82562ET & RTL8110SX)	49
BIOS Flash Utility	49
Watchdog Timer	50
Watchdog Timer Setting	51
Watchdog Timer Enabled	52
Watchdog Timer Trigger	52
Watchdog Timer Disabled	53
CANBUS	54
Defined Memory Mapping And Interrupt	54
Example Programming	55
Chapter 5 Technical Reference	57
Trouble Shooting for Post Beep and Error Messages	57
Technical Reference	60
Physical and Environmental	60
Real-Time Clock and Non-Volatile RAM	60
CMOS RAM Map	62

I/O Port Address Map.....	63
Interrupt Request Lines (IRQ).....	64
DMA Channel Map	65
DMA Controller 2.....	65
Serial Ports	66
Appendix.....	70
Dimension	70

Chapter 1 Introducing the FX5405 System

Overview

The FX5405 is an embedded system with low-power CPU module inside. This user's manual provides information on the physical features, installation, and BIOS setup of the FX5405.

Built to unleash the total potential of the Celeron-M Processor, Able to support 600MHz CPU, this system supports one 10/100/1000M Base -TX and one 10/100 Base -T LAN ports, 512MB DDR-RAM on board, mini PCI socket for wireless LAN, Four USB2.0 ports, and a VGA controller.



Each FX5405 has two ports for I/O communications, One RS-232C port and one CANBUS port. The CAN (Controller Area Network) is a serial bus system especially suited for networking "intelligent" I/O devices as well as sensors and actuators within a machine or plant. Characterized by its multi-master protocol, real-time capability, error correction, high noise immunity, and the existence of many different silicon components, the CAN serial bus system, originally developed by Bosch for use in automobiles, is increasingly being used in industrial automation.

The FX5405 is perfect for ATM machines, KIOSK, point-of- information, and infotainment, measurement technology, and small Embedded Control. The unit is only 120.0mm (D) X165.0mm (W) X65mm (H).

Series Comparison Table

Model	FX5405
Processor	Intel Celeron-M 600MHz
Chipset	852GME+ICH4
1 200 Pin-DIMM (Max.)	512MB/1GB
VGA	Yes
Watchdog Timer	Yes
Multi I/O	One RS-232C Serial
CAN-BUS	One
Enhanced IDE	One
CF (Compact Flash Socket)	One
USB 2.0	Four
Audio	Line -Out And MIC-In
RJ45 WAN port (10/100/1000Mbps)	One Giga LAN+ One 10/100Base -T
Mini-PCI Socket	One
Dimensions (Unit: mm)	120(D) x165(W) X 65(H)

Layout



Specifications

❑ ***Processor Board –***

Intel Low Power Celeron-M 600MHz CPU with 512MB DDR-RAM.

❑ ***I/O Outlets –***

One 10/100 and One 10/100/1000 base-TX Ethernet LAN ports.

Four USB ports (2.0) and one RS-232 serial port.

One CRT and one PS/2 compatible keyboard and mouse interfaces.

One Audio Line-Out and Microphone-Input.

One Mini PCI Socket for Wireless LAN module.

One DC-In plug connector and one terminal block with power switch.

One push button and one reset switch.

One power LED, One HDD/CF access LED, and two LAN LED's.

❑ ***CAN BUS –***

The CAN bus using the Philips SJA1000 controller, electrically compatible with the PCA82C200 stand-alone CAN controller chip.

- Full CAN-functionality 2.0 B.
- Extended receive buffer (64 byte FIFO).
- 16 MHz CAN Control frequency.

❑ ***Storage Bay -***

Compact Flash socket for Compact Flash modules or MicroDrives.

One 2.5" hard disk space.

❑ ***Power requirement –***

DC +9V/4A~+28V/1.3A with full loading.

❑ ***Dimensions -***

120.0mm(D) x 165.0mm(W) x 65.0mm(H)

Packing List

Upon receiving the package, verify the following things. Should any of the mentioned happens, contact us for immediate service.

- Unpack and inspect the FX5405 package for possible damage that may occur during the delivery process.
- Verify the accessories in the package according to the packing list and see if there is anything missing or incorrect package is included.
- If the cable(s) you use to install the FX5405 is not supplied from us, please make sure the specification of the cable(s) is compatible with the FX5405 system.

Note: after you install the FX5405, it is recommended that you keep the diskette or CD that contains drivers and document files, and keep the document copies, or unused cables in the carton for future use.

The following lists the accessories that may be included in your FX5405 package. Some accessories are optional items that are only shipped upon order.

- One FX5405 embedded system.
- One Y cable (3-end) PS2 Keyboard plus mouse port adapter Cable.
- One 44-pin flat cable and 4 screws for fixing and connecting 2.5" hard disk drive.
- One 2-pin apartable terminal block.
- One pack of DIN Rail mounting kit with 3 screws.
- One FX5504k1 or one FX5404K1 universal fixers and 6 screws.(Optional)
- One compact disc includes software utility and manual.

Chapter 2 Hardware Installation

This chapter introduces the system connectors & jumper settings, and guides you to apply them for field application.

Before Installation


Before you install the system, make sure you follow the following descriptions.

1. Before removing the cover, shut down the operation System and disconnect power switch to off and unplug AC-to DC Adapter cable.
2. Install any connector, Compact Flash, and hard disk be sure that the power is disconnected or power switch to off from the system. If not, this may damage the system.
3. The ESD (Electricity Static Discharge) may be created from human body that touches the board. It may do damage to the board circuit.

□ **Removing Covers -Installing Hardware**


If you are installing hardware option, you can remove the back cover. The following figure will guide you how to install 2.5" HDD inside, Compact Flash modules, mini PCI WLAN module and DDR-RAM module the FX5405 and how to install the FX5405 fixers. (Please see the spots circled.)

➤ **a. Installing Compact Flash**




Note: The Compact Flash socket supports Compact Flash Modules and Micro Drives.

➤ **b. Unscrew back cover and Installing Hard Disk**



◇ **b1. Installing Hard Disk**




Note: Use caution when handling the hard disk to prevent damage to IDE connector as you inserted hard disk. Be careful with the pin orientation when installing connectors. A wrong connection can easily destroy your hard disk.


➤ **c. Installing Mini PCI Card: Mini PCI Socket for WLAN Modules**

You may extend additional mini PCI WLAN module to FX5405 by removing the back cover and draw-out CPU modules. Connect the antenna cable from backside antenna hole to Mini PCI WLAN (the auxiliary board). Release the screws on the back of the unit. (Please see the spots circled.)

◇ **c1. Unscrew back covers and draw-out CPU modules**




◇ *c2. Unscrew transfer board and add Mini-PCI module*



➤ **d. Installing Memory: DIMM Socket For DDR Modules**


You may extend additional memory to FX5405, See as following figure and rear pictures. The DIMM socket supports 128MB to 1GB of DDR RAM modules.




➤ **e. Installing the universal fixers on FX5405**

Please refer to the down side figure for installing the FX5405 with universal fixers.


e1. FX5404K1 universal fixers.




e2. FX5504K1 universal fixers.



e3. Install DIN Rail Clips Kit on FX5405.




e3-1: DIN Rail Mounting FX5405.




□ **LED Indicators (On the Front Panel)**

The Power and HDD LED's has two distinctive statuses: Off for inactive operation and blinking light for activity. And the 2 LED's for LAN ports. The LAN1 and LAN2 LED's (Green) indicate on-line/access status of LAN1 and LAN2 respectively.





□ **Connecting the Monitor, Keyboard and Mouse**

If you are connecting the monitor, keyboard, mouse to the FX5405 using the connections provided on the side of the chassis. See following figure and a side pictures.




1. A CRT connector is provided for CRT signals



DB15	Signal
1	Red
2	Green
3	Blue
13	Hsync
14	Vsync
12	DDC Data
15	DDC Clock
5 & 10	Digital Ground
6,7,8	Analog Ground
Others	Not Used


2. The connectors use the included adapter cable you can attach standard PS/2 type keyboard and mouse. Standard PS/2 keyboard can be plugged into this connector without any adapter cable. If PS/2 keyboard and mouse will be used simultaneously, a Y-type (3-terminal) adapter cable is needed.



KB /Mouse	Description
1	Keyboard Data
2	Mouse Data
3	Ground
4	VCC
5	Keyboard Clock
6	Mouse Clock

□ **Connecting the COM port**

The DB9 (COM1) is standard serials port connector. The following tables show the signal connections of this connector.



DB-9	RS-232 Signal
1	-DCD
6	-DSR
2	RXD
7	-RTS
3	-TXD
8	-CTS
4	-DTR
9	-RI
5	Ground
Case	Case Ground

□ **Connecting the CANBUS port**

The CANBUS is use DB9 standard connector. The following tables show the CANBUS signal connections of this connector.




DB-9 CANBUS	CANBUS Signal	CANBUS Description
1	N.C	-
6	N.C	-
2	CAN-L	Dominant Low
7	CAN-H	Dominant High
3	CAN-Ground	Isolated Ground
8	N.C	-
4	N.C	-
9	N.C	-
5	Ground	Digital Ground
Case	Case Ground	

Note: The CANBUS DB9-pin out conforms to the ISO 11898/2 standard specification.

□ **Connecting the L1/L2 LAN ports and USB Ports**

The RJ45 connector with 2 LED's for WAN/LAN. The right side LED (orange) indicates data is being accessed and the right side LED (green) indicates on-line status. (On indicates on-line and off indicates off-line)


RJ45 connector



The following lists the pin assignment of RJ45.

RJ45	LAN1	LAN2	RJ45	LAN1	LAN2
1	TPTX+	TPTX+	5	FBG1	TPTX1-
2	TPTX -	TPTX -	6	TPRX -	TPRX -
3	TPRX+	TPRX+	7	FBG2	TPRX1+
4	FBG1	TPTX1+	8	FBG2	TPRX1-

The FX5405 supports a four port USB connector. Any USB device can be attached to USB ports with plug-and-play supported. The left side port is USB # 1/2 and the right side port is USB # 3/4



USB#1~4	Signal
Pin 1	USBV
Pin 2	USBD-
Pin 3	USBD+
Pin 4	USBG

□ **Connecting the Audio Microphone In/ Speak Out**



Mic-In





Line-Out

□ **Connecting the DC Power and Power Button**



Power is supplied through an external AC/DC power adapter or power DC In. Check the technical specification section for information about AC/DC power input voltage. See following figure and a side pictures.

1. DC-Power Jack: Use External AC/DC power adapter




DC +9~+28V, 45VA minimum

2. DC Power Connector: Use external 2-pin apart able terminal block. (Please see the spots circled.)



Terminal Block


- Power Button & Reset Push Button: Pushing the Power button once will switch the FX5405 on and off, depending on system BIOS (Advanced Chipset Setting>Southbridge Configuration>Restore AC power). And Reset push button is switcher for system reset; Push and release the button will cause hard ware reset of FX5405 and restart system booting.




□ **Jumper Setting**

The Serial port 1 is designed for multiple proposes, Use JP1/JP3 of the transfer board selects RS-232, RS422 or RS-485 of COM1 connector, Use JP2 selects CANBUS Terminal resistor (Please see the **b. transfer board** spots circled.), and J3,JP1,JP2 of CPU board is used to select clean CMOS data, Line-In, Mic-In and WOL(wake up On LAN).


➤ **a. CPU board**



➤ b. Transfer board



DB-9	RS-232	RS-422	RS-485
1	-DCD		
6	-DSR		
2	RXD	RX-	485-
7	-RTS	TX-	
3	-TXD	RX+	485+
8	-CTS	TX+	
4	-DTR		
9	-RI		
5	Ground		
Metal	Case Ground		



Note: The JP2 is the CAN bus termination jumper. Only two termination jumpers should be closed at the endpoints of the CAN bus. Value Terminator Resistor (120 Ω)

Chapter 3 BIOS Setup

This chapter describes the BIOS setup.

Overview

BIOS are a program located on a Flash memory chip on a circuit board. It is used to initialize and set up the I/O peripherals and interface cards of the system, which includes time, date, hard disk drive, the ISA bus and connected devices such as the video display, diskette drive, and the keyboard. This program will not be lost when you turn off the system.


The BIOS provides a menu-driven interface to the console subsystem. The console subsystem contains special software, called firmware that interacts directly with the hardware components and facilitates interaction between the system hardware and the operating system.

The BIOS default values ensure that the system will function at its normal capability. In the worst situation the user may have corrupted the original settings set by the manufacturer.

All the changes you make will be saved in the system RAM and will not be lost after power-off.

When you start the system, the BIOS will perform a self-diagnostics test called Power On Self Test (POST) for all the attached devices, accessories, and the system. Press the [Del] key to enter the BIOS Setup program, and then the main menu will show on the screen.

Note: Change the parameters when you fully understand their functions and subsequence.



□ BIOS Functions

On the menu, you can perform the following functions

1. Main
2. Advanced
 - CPU Configuration
 - IDE Configuration
 - SuperIO Configuration
 - Hardware Health Configuration
 - ACPI Function
 - USB Configuration
3. PCIPnP
4. Boot
 - Boot Settings Configuration
 - Boot Device Priority
 - Hard Disk Drives
 - Removable Drivers
5. Security
 - Change Supervisor Password
 - Change User Password
 - Boot Sector Virus Protection
6. Chipset
 - NorthBridge Configuration

- SouthBridge Configuration
- 7. Power
- 8. Exit
 - Save Changes and Exit: Exit system setup after saving the changes.F10 key can be used for this operation.
 - Discard Changes and Exit: Exit system setup without saving any changes. ESC key can be used for this operation.
 - Discard Changes: Discard changes down so far any of the set questions. F7 key can be used this operation.
 - Load Optimized Default: to auto configure the system according to optimal setting with pre-defined values. This is also the factory default setting of the system when you receive the board.
 - Load Fail-Safe Default: to configure the system in fail-safe mode with predefined values.


Keyboard Convention

On the BIOS, the following keys can be used to operate and manage the menu:

Item	Function
ESC	To exit the current menu or message
Page Up/Page Down	To select a parameter
F1	To display the help menu if you do not know the purpose or function of the item you are going to configure
F8	Fail-Safe Default
F9	Optimized Default
F10	Save and exit
UP/Down Arrow Keys	To go upward or downward to the desired item

Main Setup

This section describes basic system hardware configuration, system clock setup and BIOS version information. If the CPU board is already installed in a working system, you will not need to select this option anymore.



➤ System Memory

This option is display-only which is determined by POST (Power On Self Test) of the BIOS.

➤ System Date & Time Setup


Highlight the <Date> field and then press the [Page Up] / [Page Down] or [+]/ [-] keys to set the current date. Follow the month, day and year format.

Highlight the <Time> field and then press the [Page Up] / [Page Down] or [+]/ [-] keys to set the current date. Follow the hour, minute and second format.

The user can bypass the date and time prompts by creating an AUTOEXEC.BAT file. For information on how to create this file, please refer to the MS-DOS manual.

Advanced Setup

Select the *Advanced* tab from the setup screen to enter the Advanced BIOS Setup screen. You can select any of the items in the left frame of the screen, such as SuperIO Configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screen is shown below. The sub menus are described on the following pages




➤ CPU Configuration

You can use this screen to select options for the CPU information. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

Note: The CPU Configuration setup screen varies depending on the installed processor.

➤ IDE Configuration

You can use this screen to select options for the IDE Configuration Settings. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option. A description of the selected item appears on the right side of the screen. The settings are described on the following pages. An example of the *IDE Configuration* screen is shown below.



➤ **OnBoard PCI IDE Controller**

This item specifies the IDE channels used by the onboard PCI IDE controller

Available Options: Primary, Secondary, Both and Disable

Default setting: Both

➤ **OnBoard PCI IDE Operate Mode**

This item specifies the Native Mode Only for Windows® XP and 2000.

Available Options: Legacy Mode and Native Mode

Default setting: Legacy Mode

➤ **IDE Primary/Secondary Master/Slave**

IDE hard drive controllers can support up to two separate hard drives. These drives have a master/slave relationship, which is determined by the cabling configuration used to attach them to the controller. Your system supports one IDE controller – a primary and a secondary – so you have the ability to install up to four separate hard disks.

LBA/Large Mode

LBA (Logical Block Addressing) is a method of addressing data on a disk drive. In

LBA mode, the maximum drive capacity is 137 GB. The Optimal and Fail-Safe default setting is *Auto*

Hard Disk Type

The BIOS supports various types for user settings, The BIOS supports <Pri Master>, <Pri Slave>, so the user can install up to two hard disks. For the master and slave jumpers, please refer to the hard disk's installation descriptions and the hard disk jumper settings.

You can select <AUTO> under the <TYPE> and <MODE> fields. This will enable auto detection of your IDE drives during boot up. This will allow you to change your hard drives (with the power off) and then power on without having to reconfigure your hard drive type. If you use older hard disk drives, which do not support this feature, then you must configure the hard disk drive in the standard method as described above by the <USER> option.

PIO MODE

PIO means Programmed Input/Output. Rather than have the BIOS issue a series of commands to affect a transfer to or from the disk drive, PIO allows the BIOS to tell the controller what it wants and then let the controller and the CPU perform the complete task by them. This is simpler and more efficient (and faster). Your system supports five modes, numbered from 0 to 4, which primarily differ in timing. When Auto is selected, the BIOS will select the best available mode.

BLOCK (Multi-Sector Transfer)

This option allows your hard disk controller to use the fast block mode to transfer data to and from your hard disk drive (HDD).

S.M.A.R.T

This field is used to activate the S.M.A.R.T (System Management and Reporting Technologies) function for S.M.A.R.T HDD drives. This function requires an application that can give S.M.A.R.T message.

32 Bit Data Transfer

This option sets the 32-bit data transfer option. The Optimal and Fail-Safe default setting is *Enabled*.

➤ Hard Disk Write Protect

Set this option to protect the hard disk drive from being overwritten. The Optimal and Fail-Safe default setting is *Disabled*.

Available Options: Disabled, Enabled

Default setting: Disable

➤ **IDE Detect Time Out (Sec.)**

Set this option to stop the AMIBIOS from searching for IDE devices within the specified number of seconds. Basically, this allows you to fine-tune the settings to allow for faster boot times. Adjust this setting until a suitable timing that can detect all IDE disk drives attached is found.

Available Options: 0, 5, 10, 15, 20, 25, 30, and 35

Default setting: 35

➤ **ATA(PI) 80 Pin Cable Detection**

Set this option to select the method used to detect the ATA (PI) 80 pin cable. The use of an 80-conductor ATA cable is mandatory for running Ultra ATA/66, Ultra ATA/100 and Ultra ATA/133 IDE hard disk drives. The standard 40-conductor ATA cable cannot handle the higher speeds.

Available options: Host & Device, Host, and Device

Default setting: Host & Device

➤ **SuperIO Chipset - Configuration WIN627 Super IO Chipset**

This section describes the function of Super I/O settings.

BIOS SETUP UTILITY	
Advanced	
Configure Win627 Super IO Chipset	
KBC Clock Rate Selection	[8MHz]
Serial Port1 Address	[3F8/IRQ4]
KBC Clock rate selecti 6Mhz/8MHz/12MHz/16MHz Controller.	
↔ Select Screen ↑↓ Select Item +- Change Option F1 General Help F10 Save and Exit ESC Exit	
v02.58 (C) Copyright 1985-2004, American Megatrends, Inc.	

➤ **Serial Port 1 Address**

These fields select the I/O port address for each Serial port.

Available Options: Disabled, 3F8H/IRQ4, 3E8H/IRQ4, and 2E8H/IRQ3.


Default setting: 3F8H/IRQ4

➤ **Hardware Health Configuration**

On the Hardware Monitor Setup screen, you can monitor the system temperature, CPU voltage, and CPU fan speed...

BIOS SETUP UTILITY	
Advanced	
Hardware Health Configuration	
H/W Health Function	[Enabled]
Hardware Health Event Monitoring	
System Temperature	:51°C/123°F
External Temperature	:-51°C/123°F
CPU Temperature	:66°C/150°F
CPU Vcore	:1.000 V
Chipset Vcore	:2.516 V
+3.3Vin	:3.306 V
+5Vin	:5.022 V
+1.05Vin	:1.032 V
+1.5Vin	:1.500 V
VBAT	:3.032 V
↳ Enables Hardware Health Monitoring Device.	
↔ Select Screen ↑↓ Select Item +- Change Option F1 General Help F10 Save and Exit ESC Exit	
v02.58 (C) Copyright 1985-2004, American Megatrends, Inc.	

➤ **Advanced ACPI Settings**



➤ **ACPI Aware O/S**

This field specifies allow you set this value to utilize the ACPI (Advanced Configuration and Power Interface) specification.

Available Options: Yes, and No

Default setting: Yes

■ **Advanced ACPI Configuration**

ACPI 2.0 Feature

Set this value to allow or prevent the system to be compliant with the ACPI 2.0 Specification.

Available Options: Yes, and No

Default setting: Yes

AMI OEMB Table

Set this value to allow the ACPI BIOS to add a pointer to an OEMB table in the Root System Description Table (RSDT) table.

Available Options: Enable, and Disable

Default setting: Enable

■ **Chipset ACPI Configuration**

APIC ACPI SCI IRQ


Allows you to enable or disable the internal I/O APIC and Multiprocessor Tables. (Disable the APIC ACPI SCI IRQ may require the O.S. to be reinstalled)

Available Options: Disable, and Enable

Default setting: Disable

➤ **USB Configuration**

You can use this screen to select options for the USB Configuration.



➤ **USB Function**

Set this value to allow the system to enable or disable the onboard USB ports. The Optimal and Fail-Safe default setting is 4 USB Ports.

Available Options: 2 USB Ports, 4 USB Ports and Disabled

Default setting: 4 USB Ports

➤ **Legacy USB Support**

Legacy USB Support refers to the USB mouse and USB keyboard support. Normally if this option is not enabled, any attached USB mouse or USB keyboard will not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB drivers loaded on the system. Set this value to enable or disable the Legacy USB Support.

Available Options: Disabled, Enabled and AUTO

Default setting: Enable

➤ **USB 2.0 Controller**

This field is Enables USB controllers. Select Enable, if a USB device is installed to the system. If Disabled are selected, the system will not be able to use a USB device.

Available Options: Enable, and Disabled

Default setting: Enable

➤ **USB 2.0 Controller Mode**

This field is configures the USB 2.0 controllers in High speed (480Mbps) or Full speed (12Mbps).

Available Options: HiSpeed and FullSpeed

Default setting: Hispeed

➤ **BIOS ECHI Hand-Off**

This is a workaround for OS without ECHI Hand-Off support. The ECHI ownership change should claim by ECHI driver.

Available Options: Enable and Disable

Default setting: Enable

PCIPnP Setup

Select the *PCI/PnP* tab from the setup screen to enter the Plug and Play BIOS Setup screen. You can display a Plug and Play BIOS Setup option by highlighting it using the <Arrow> keys. All Plug and Play BIOS Setup options are described in this section. The Plug and Play BIOS Setup screen is shown below.



➤ **Clean NVRAM**

Clean NVRAM during system boot.

Available Options: Yes, No

Default setting: No

➤ **Plug and Plug Aware O/S**

Set to Yes to inform BIOS that the operating system can handle Plug and Play (PnP) devices.

Available Options: Yes, No

Default setting: No

➤ **PCI Latency Timer**

This field specifies the latency timings (in PCI clock) PCI devices installed in the PCI expansion bus.

Available Options: 32, 64, 96, 128, 160,192, 224, and 248

Default setting: 64

➤ **Palette Snoop**

When Enabled is selected, multiple VGA devices operating on different buses can handle data from the CPU on each set of palette registers on every video device. Bit 5 of the command register in the PCI device configuration space is the VGA Palette Snoop bit. (0 is disabled).

Available Options:

Disabled: Data read and written by the CPU is only directed to the PCI VGA devices palette registers.

Enabled: Data read and written by the CPU is directed to both the PCI VGA devices palette registers.

Default setting: Disable

➤ **PCI IDE BusMaster**

This option is to specify that the IDE controller on the PCI local bus have bus-mastering capability.

Available Options: Enable, Disable

Default setting: Disable

➤ **IRQ 3 -15**

When I/O resources are controlled manually, you can assign each system interrupt as one of the following types, based on the type of device using the interrupt:

Available: Specified IRQ is available to the used by PCI/PnP devices.

Reserved: Specified IRQ is reserved for used by Legacy ISA devices.

Available Options: Available and Reserved

Default setting: Available

➤ **DMA Channel 0 – 7**

When I/O resources are controlled manually, you can assign each system DMA as one of the following types, based on the type of device using the interrupt:

Available: Specified IRQ is available to be used by PCI/PnP devices.

Reserved: Specified IRQ is reserved for use by Legacy ISA devices.

Available Options: Available and Reserved

Default setting: Available


Boot Setup

Select the *Boot* tab from the setup screen to enter the Boot BIOS Setup screen. You can select any of the items in the left frame of the screen, such as Boot Device Priority, to go to the sub menu for that item. You can display a Boot BIOS Setup option by highlighting it using the <Arrow> keys. All Boot Setup options are described in this section. Select an item on the Boot Setup screen to access the sub menu for:

- BIOS Setting Configuration
- Boot Device Priority
- Hard disk drives



➤ **Boot Setting Configuration**



➤ **Quick Boot**

This field is used to activate the quick boot function of the system. When set to Enabled,

1. BIOS will not wait for up to 40 seconds if a Ready signal is not received from the IDE drive, and will not configure its drive.
2. BIOS will not wait for 0.5 seconds after sending a RESET signal to the IDE drive.
3. You cannot run BIOS Setup at system boot since there is no delay for the Hit, Del. To run Setup message.

Available Options: Disabled, Enabled

Default setting: Enabled

➤ **Boot Up Num-Lock**

This field is used to activate the Num Lock function upon system boot. If the setting is on, after a boot, the Num Lock light is lit, and user can use the number key.

Available options: On, Off

Default setting: On

➤ **PS/2 Mouse Support**

The PS/2 mouse function is optional. Before you configure this field, make sure your FX5632 supports this feature. The setting of **Enabled** allows the system to detect a PS/2 mouse on boot up. If detected, IRQ12 will be used for the PS/2 mouse. IRQ 12 will be reserved for expansion cards if a PS/2 mouse is not detected. **Disabled** will reserve IRQ12 for expansion cards and therefore the PS/2 mouse will not function.

Available options: Disabled, Enabled and Auto

Default setting: Auto

➤ **Wait for 'F1' If Error**

AMIBIOS POST error messages are followed by:

Press <F1> to continue

If this field is set to **Disabled**, the AMIBIOS does not wait for you to press the <F1> key after an error message.

Available options: Disabled, Enabled

Default setting: Disabled

➤ **Hit 'DEL' Message Display**

Set this field to **Disabled** to prevent the message as follows:

Hit 'DEL' if you want to run setup


It will prevent the message from appearing on the first BIOS screen when the computer boots.

Available options: Disabled, Enabled

Default setting: Enabled

➤ **Boot Device**

Use this screen to specify the order in which the system checks for the device to boot from. To access this screen, select Boot Device Priority on the Boot Setup screen and press <Enter>.



➤ **First /Second /Third Hard Disk Boot Device**

Set the boot device options to determine the sequence in which the computer checks which device to boot from. The settings are *Removable Dev.*, *Hard Drive*, or *ATAPI CDROM*.

Note: When you select a boot category from the boot menu, a list of devices in that category appears. For example, if the system has three hard disk drives connected, then the list will show all three hard disk drives attached

➤ **Hard Disk Drives**

Use this screen to view the hard disk drives in the system. To access this screen, select Hard disk drives on the Boot Setup screen and press <Enter>.



Security setup

There are two security passwords: Supervisor and User. Supervisor is a privileged person that can change the User password from the BIOS. According to the default setting, both access passwords are not set up and are only valid after you set the password from the BIOS.

- Change Supervisor Password
- Change User Password
- Clear User Password
- Boot Sector Virus Protection



To set the password, please complete the following steps.

1. Select **Change Supervisor Password**.
2. Type the desired password (up to 6 character length) when you see the message, "Enter New Supervisor Password."
3. Then you can go on to set a user password (up to 6 character length) if required. Note that you cannot configure the User password until the Supervisor password is set up.
4. Enter Advanced BIOS Features screen and point to the Security Option field.

5. Select System or Setup.
 - ✧ **Always:** a visitor who attempts to enter BIOS or operating system will be prompted for password.
 - ✧ **Setup:** a visitor who attempts to the operating system will be prompted for user password. You can enter either User password or Supervisor password.
6. Point to **Save Settings and Exit** and press Enter.
7. Press Y when you see the message, "Save Current Settings and Exit (Y/N)?"

Note: it is suggested that you write down the password in a safe place to avoid that password may be forgotten or missing.

➤ **Clean User Password**

Select Clear User Password from the Security Setup menu and press <Enter>. Clear New Password > [Ok] [Cancel] appears. Type the password and press <Enter>. The screen does not display the characters entered. Retype the password as prompted and press <Enter>.

➤ **Password Check**

This field enables password checking every time the computer is powered on or every time the BIOS Setup is executed. If **Always** is chosen, a user password prompt appears every time and the BIOS Setup Program executes and the computer is turned on. If **Setup** is chosen, the password prompt appears if the BIOS executed.

Available options: Setup, Always

Default setting: Setup

➤ **Boot Sector Virus Protection**

This option is near the bottom of the Security Setup screen. The Optimal and Fail-Safe default setting is *Disabled*

Disable: Set this value to prevent the Boot Sector Virus Protection. This is the default setting.

Enable: Select Enabled to enable boot sector protection, Displays a warning when any program (or virus) issues a Disk Format command or attempts to write to the boot sector of the hard disk drive. If enabled, the following appears when a write is attempted to the boot sector. You may have to type N several times to prevent the boot sector write. Boot Sector Write!

Possible VIRUS: Continue (Y/N)? _

The following appears after any attempt to format any cylinder, head, or sector of any hard disk drive via the BIOS INT 13 Hard disk drive Service:

Format!!!

Possible VIRUS: Continue (Y/N)?

Chipset Setup

This section describes the configuration of the board's chipset features.

- NorthBridge Configuration
- SouthBridge Configuration



➤ Northbridge Configuration

You can use this screen to select options for the North Bridge Configuration. Use the up and down <Arrow> keys to select an item. Use the <Plus> and <Minus> keys to change the value of the selected option.

➤ DRAM Frequency

This specifies the SDRAM memory clock frequency.

Available Options: Auto, 200MHz, 266MHz, and 333MHz

Default setting: Auto

➤ **Configure DRAM Timing by SPD**

SPD represents Serial Presence Detect. It is an 8-bit, 2048 bits EEPROM, built on the SDRAM for 100 MHz frequencies. If the installed SDRAM supports SPD function, select SPD. If not, you can select based on other access time of the SDRAM.

Available Options: Disabled and Enabled

Default setting: Enable

➤ **Internal Graphics Mode Select**

This field is share memory architecture (SMA) for frame buffer memory. SMA allows system memory to be efficiently share by the host CPU and allocated depending on user preference, application requirements, and total size of system memory.

Available Options: Disable, 1MB, 4MB, 8MB, 16MB and 32MB

Default setting: 8MB

➤ **Graphics Aperture Size**

This field specifies the system memory size that can be used by the Accelerated Graphics Port (AGP).

Available Options: 64MB, 128MB and 256MB

Default setting: 64 MB

➤ **Southbridge Configuration**

You can use this screen to select options for the South Bridge Configuration. South Bridge is a chipset on the motherboard that controls the basic I/O functions, LAN port, and audio function.

➤ **Onboard AC'97 Audio**

This field specifies the internal Audio Control.

Available Options: Disable and Auto

Default setting: Auto

➤ **On Board LAN1/2 Controller**

This field specifies the Enable or Disable of the onboard LAN chip.

Available Options: Disabled, Enable

Default setting: Enable

➤ **On Board LAN1/LAN2 Boot ROM**

This field specifies the PXE boot ROM of the onboard LAN chip.

Available Options: Disabled, Enable

Default setting: Disable

➤ **Restore on AC Power Loss**

This field specifies the option controls how the PC will behave once power is restored following a power outage (or other unexpected or ungraceful shutdown). The "Last State" option returns the PC to the state in effect at the time the power outage or shutdown occurred. Assign this option the "Power On" value to reboot automatically; assign the "Power Off" value to leave the machine powered down.

Available Options: Power Off, Power On, and Last State

Default setting: Power Off

POWER MANAGEMENT



➤ Power Management/APM

Select Enabled to activate the chipset Power Management and APM (Advanced Power Management) features.

Available Options: Disable and Enable

Default setting: Enable

➤ Video Power Down Mode

This field specifies the power conserving state that video subsystem enters after the specified period of display inactivity has expired.

Available Options: Disabled, Standby, Suspend

Default setting: Disabled

➤ **Hard Disk Power Down Mode**

This field specifies the power conserving state that the hard disk drive enters after the specified period of hard drive inactivity has expired.

Available Options: Disabled, Standby, Suspend

Default setting: Disabled

➤ **Standby Time Out (Minute)**

This field specifies the length of a period of system inactivity (like hard disk or video) while in full power on state. When this length of time expires, the system enters Standby power state.

Available Options: Disabled, 1 Minute, 2 Minute, 4 Minute, and 8 Minute, up to 60 Minute.

Default setting: Disabled

➤ **Power Button Mode**

This option specifies go into On/Off or Suspend when power button is pressed.

Available Options: On/Off, and Suspend.

Default setting: On/Off

➤ **Resume On RTC Alarm**

This field specifies the RTC alarm to be turned off by extra software.

Available Options: Disabled, Enabled

Default setting: Disabled

■ ***RTC Alarm Date (Days)***

This field specifies the date of the RTC alarm.

Available Options: Every day, and 01~ 31

Default setting: 15

■ ***System Time (hh:mm:ss)***

This field specifies the hour/ minute/second of the RTC alarm.

Available Options: 1-24/0-60/0-60

Default setting: 12:30:30

Chapter 4 Software Installation

The enclosed diskette includes FX5405 VGA, Audio, USB, System, CANBUS and LAN driver. To install and configure you FX5405 system, you need to perform the following steps.

System Driver

WIN 98/2000/XP Driver

Installs 852GME Chipset, IRQ Routing, USB, AGP Driver and ISA IDE Bus Master Drive.

- Step 1: To install the 852GME driver, insert the CD ROM into the CD ROM device, and enter DRIVER>SysChip>855GME.
- Step 2: Execute Setup.exe file.
- Step 3: The screen shows the SETUP type. Press any key to enter the main menu.
- Step 4: As the setup is completed, the system will generate the message as follows.

Yes, I want to restart my computer now. Installation is done!

No, I will restart my computer later.

System must be restart then complete the installation.

Note: In the Syschip>855GME directory, a Readme.txt file is included to provide installation information.

VGA Driver for WIN98SE/ME/2000/XP/NT4.0

Step 1: To install the VGA driver, insert the CD ROM into the CD ROM device, and enter DRIVER>VGA>855GME>WIN2K_XP, WIN98_ME or WINNT4.

Step 2: Execute SETUP.EXE file.

Step 3: The screen shows the SETUP type. Press any key to enter the main menu.

Step 4: As the setup is completed, the system will generate the message as follows.

Yes, I want to restart my computer now. Installation is done!

No, I will restart my computer later.

System must be restart then complete the installation.

Step 5: In the WINDOWS2000/XP/98SE/ME, you can find the <DISPLAYL> icon located in the {CONTROL PANEL} group.

Step 6: Adjust the <Refresh Rate>, and <Resolution>.

Audio Drivers

WIN 98/2000/XP Driver

Step 1: To install the AUDIO driver, insert the CD ROM into the CD ROM device, and enter DRIVER>AUDIO>I815E>WIN98&ME&2K&XP.

Step 2: Execute SETUP.exe file.

Step 3: The screen shows the SETUP type. Press any key to enter the main menu.

Step 4: As the setup is completed, the system will generate the message as follows.

Yes, I want to restart my computer now. Installation is done!

No, I will restart my computer later.

System must be restart then complete the installation.

Note: In the DRIVER>AUDIO>I815E> WIN98&ME&2K&XP or WINNT40 directory, a Readme.txt file is included to provide installation information.

USB 2.0 Driver

WIN 98 Driver

- Step 1: To install the USB driver, insert the CD ROM into the CD ROM device, and enter DRIVER>USB>855GME>WIN2K, WINXP, WIN98_ME.
- Step 2: Start the "Add New Hardware" wizard in control panel
(Click Start/Settings/Control Panel).
- Step 3: Select "Hardware" and click "Device Manager" button.
- Step 4: Double Click "USB Root Hub".
- Step 5: Select "Driver".
- Step 6: Click "Install" to install the driver.
- Step 7: Follow the instructions on the screen to complete the installation.
- Step 8: Click "Finish" after the driver installation is complete.

LAN Utility & Driver (82562ET & RTL8110SX)

- 1 To install the LAN utility OR driver, insert the CD ROM into the CD ROM device, and enter DRIVER>LAN>82562ET and DRIVER > LAN >RTL8110SX >DIAG. If your system is not equipped with a CD ROM device, copy the LAN driver from the CD ROM to CF.
- 2 Execute Pro2kxp.exe and install2KXP.exe file.

Note: In the LAN>82562ET and LAN>RTL8110SX directory, a README.TXT is included to provide installation information.

BIOS Flash Utility


In the <UTILITY> directory, there is the Afu409.EXE file.

- Step 1: Use the Afu409.EXE program to update the BIOS setting.
- Step 2: And then refer to the chapter "BIOS Setup", as the steps to modify BIOS.
- Step 3: Now the CPU board's BIOS loaded with are the newest program; user can use it to modify BIOS function in the future, when the BIOS add some functions.

Watchdog Timer

This section describes how to use the Watchdog Timer, including disabled, enabled, and trigger functions.

The FX5405 is equipped with a programmable time-out period watchdog timer. You can use your own program to enable the watchdog timer. Once you have enabled the watchdog timer, the program should trigger the I/O every time before the timer times out. If your program fails to trigger or disable this timer before it times out, e.g. because of a system hang-up, it will generate a reset signal to reset the system. The time-out period can be programmed to be set from 1 to 255 seconds or minutes.



Watchdog Timer Setting

The watchdog timer is a circuit that may be used from your program software to detect system crashes or hang-ups. LED1 on this CPU board is the watchdog timer indicator, which is located at the upper-left corner above the USB connector. Whenever the watchdog timer is enabled, the LED will blink to indicate that the timer is counting. The watchdog timer is automatically disabled after reset.

Once you have enabled the watchdog timer, your program must trigger the watchdog timer every time before it times out. After you trigger the watchdog timer, it will be set to non-zero value to watchdog counter and start to count down again. If your program fails to trigger the watchdog timer before time-out, it will generate a reset pulse to reset the system.

The factor of the watchdog timer time-out constant is approximately 1 second. The period for the watchdog timer time-out is between 1 to FF timer factors.

If you want to reset your system when watchdog times out, the following table listed the relation of timer factors between time-out periods.

Time Factor	Time-Out Period (Seconds)	Time-Out Period (Minutes)
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
"	"	"
"	"	"
"	"	"
FF	FF	FF

Watchdog Timer Enabled

To enable the watchdog timer, you have to output a byte of timer factor to the watchdog register whose address is 2Eh and data port is 2fH. The following is an Assemble program, which demonstrates how to enable the watchdog timer and set the time-out period at 28 seconds.

```
-----  
; Enter the extended function mode, interruptible double-write  
-----  
Mov     dx, 2eh           ; Enter to extended function mode  
Mov     al, 87h  
Out     dx, al  
Out     dx, al  
Mov     al, 07h  
Out     dx, al  
-----  
; Logical device 8, configuration register CRF5 Bit 3, CRF6 Bit 0-7  
-----  
Mov     dx, 2fh  
Mov     al, 08h           ; Select Logical Device 8 of watchdog timer  
Out     dx, al  
Mov     dx, 2eh  
Mov     al, 0f5h         ; Set second as counting unit  
Out     dx, al  
Mov     dx, 2fh  
In      al, dx  
Or      al, c0           ; Trigger P/W LED.  
And     al, not c8h      ; Set Second.  
; And   al, c8h         ; Set Minute.  
Out     dx, al  
Mov     dx, 2eh  
Mov     al, 0f6h  
Out     dx, al  
Mov     dx, 2fh  
Mov     al, 28h         ; Set timeout interval as 28seconds and start counting  
Out     dx, al  
-----  
; Exit extended function mode  
-----  
Mov     dx, 2eh  
Mov     al, 0aah  
Out     dx, al
```

Watchdog Timer Trigger

After you enable the watchdog timer, your program must write the same factor as enabling to the watchdog register at least once every time-out period to its previous setting. You can change the time-out period by writing another timer factor to the watchdog register at any time, and you must trigger the watchdog before the new time-out period in next trigger.


Watchdog Timer Disabled

To disable the watchdog timer, simply write a 00H to the watchdog register.

```
-----  
; Enter the extended function mode, interruptible double-write  
-----  
Mov    dx,2eh      ; Enter to extended function mode  
Mov    al,87h  
Out    dx,al  
Out    dx,al  
-----  
; Logical device 8, configuration register CRF5 Bit 3(Sec./Min.), CRF6 Bit 0~7 (Count.)  
-----  
-  
Mov    al,07h  
Out    dx,al  
Mov    dx,2fh  
Mov    al,08h      ; Select Logical Device 8 of watchdog timer  
Out    dx,al  
Mov    dx,2eh  
Mov    al,0f5h     ;Set second as counting unit  
Out    dx,al  
Mov    dx,2fh  
In     al,dx  
And    al,not c8h  ;Set Second or Minute.  
Out    dx,al  
Mov    dx,2eh  
Mov    al,0f6h  
Out    dx,al  
Mov    dx,2fh  
Mov    al,00h     ; Set Watchdog Timer Disabled  
Out    dx,al  
-----  
; Exit extended function mode  
-----  
Mov    dx,2eh     ;Exit the extended function mode  
Mov    al,0aah  
Out    dx,al
```

CANBUS

This section describes how to program and use the CAN BUS. it provides a Description of the I/O memory map of the chip and discussion of the internal registers to aid you in programming your CAN controller chip.



Defined Memory Mapping And Interrupt

The CANBUS occupies 2 bytes of FX5405 memory space. You can set the base address and access to the internal resources of the SJA1000 CAN controller chip. The SJA1000 chip access is multiplexed in such a way that the host must first write to 300h the internal address of the CAN chip and after that perform a write to address 301h with the actual data to be written into the desired memory location. Address 302h is a hardware-reset function of the SJA1000. Performing a read or write to this address will cause a hardware reset to the CAN controller. You may need to reset the chip in case of an unrecoverable error in the CAN controller chip. And you can use interrupt the main processor when a message is received or transmitted if interrupts are enabled on the FX5405. By using interrupts you can write powerful code to CAN.

Description	Factory Setting
Base Address	300H
Data Of Address	301H
Hardware Reset Of SJA1000 Chips	302H
Interrupt Require Quest	11

Example Programming

Write 300H to the CAN controller Control byte located in the on-chip address 0. The Example is listed below:

Outportb (0x300,0x00) ; Write CAN Address 0 (Control Register)

Outportb (0x301,0x78) ; Write Data of CAN Address 0 (Control Register)

Note: In the DRIVER/CANBUS/SJA1000 directory a demo file is included to provide CAN control information and Turbo-C DEMO program. And Please see "SJA1000.pdf" on your CD-ROM for further information on the SJA1000 chip.

Chapter 5 Technical Reference

This section outlines the errors that may occur when you operate the system, and also gives you the suggestions on solving the problems.

Topic include:

- Trouble Shooting for Post Beep & Error Messages
- Technical Reference

Trouble Shooting for Post Beep and Error Messages

The following information informs the Post Beep & error messages. Please adjust your systems according to the messages below. Make sure all the components and connectors are in proper position and firmly attached. If the errors still exist, please contact with your distributor for maintenance.

➤ **POST BEEP**

Currently there are two kinds of beep codes in BIOS setup.

- One indicates that a video error has occurred and the BIOS cannot initialize the video screen to display any additional information. This beep code consists of a single long beep followed by three short beeps.
- The other indicates that an error has occurred in your DRAM. This beep code consists of a constant single long beep.

➤ **CMOS BATTERY FAILURE**

When the CMOS battery is out of work or has run out, the user has to replace it with a new battery.

➤ **CMOS CHECKSUM ERROR**

This error informs that the CMOS has corrupted. When the battery runs weak, this situation might happen. Please check the battery and change a new one when necessary.

➤ **DISK BOOT FAILURE**

When you can't find the boot device, insert a system disk into Drive A and press < Enter >. Make sure both the controller and cables are all in proper positions, and also make sure the disk is formatted. Then reboot the system.

➤ **DISKETTE DRIVES OR TYPES MISMATCH ERROR**

When the diskette drive type is different from CMOS, please run setup or configure the drive again.

➤ **ERROR ENCOUNTERED INITIALIZING HARD DRIVE**

When you can't initialize the hard drive, ensure the following things:

1. The adapter is installed correctly
2. All cables are correctly and firmly attached
3. The correct hard drive type is selected in BIOS Setup

➤ **ERROR INITIALIZING HARD DISK CONTROLLER**

When this error occurs, ensure the following things:

1. The cord is exactly installed in the bus.
2. The correct hard drive type is selected in BIOS Setup
3. Whether all of the jumpers are set correctly in the hard drive

➤ **FLOPPY DISK CONTROLLER ERROR OR NO CONTROLLER PRESENT**

When you cannot find or initialize the floppy drive controller, please ensure the controller is in proper BIOS Setup. If there is no floppy drive installed, ensure the Diskette Drive selection in Setup is set to NONE.

➤ **KEYBOARD ERROR OR NO KEYBOARD PRESENT**

When this situation happens, please check keyboard attachment and no keys being pressed during the boot. If you are purposely configuring the system without a keyboard, set the error halt condition in BIOS Setup to HALT ON ALL, BUT KEYBOARD. This will cause the BIOS to ignore the missing keyboard and continue the boot procedure.

➤ **MEMORY ADDRESS ERROR**

When the memory address indicates error, you can use this location along with the memory map for your system to find and replace the bad memory chips.

➤ **MEMORY SIZE HAS CHANGED**

Memory has been added or removed since last boot. In EISA mode, use Configuration Utility to re-configure the memory configuration. In ISA mode enter BIOS Setup and enter the new memory size in the memory fields.

➤ **MEMORY VERIFYING ERROR**

It indicates an error verifying a value is already written to memory. Use the location along with your system's memory map to locate the bad chip.

➤ **OFFENDING ADDRESS MISSING**

This message is used in connection with the I/O CHANNEL CHECK and RAM PARITY ERROR messages when the segment that has caused the problem cannot be isolated.

➤ **REBOOT ERROR**

When this error occurs that requires you to reboot. Press any key and the system will reboot.

➤ **SYSTEM HALTED**

Indicates the present boot attempt has been aborted and the system must be rebooted. Press and hold down the CTRL and ALT keys and press DEL.

Technical Reference

Physical and Environmental

Temperature: Operating 0°C ~ 50°C

Relative humidity 5 % to 95 % non-condensing

DC-AC adapter

Input AC Voltage Range: 100V~240V/1A, 50Hz ~60Hz

Output DC Voltage: 19V/3.42A Maximal

Surface Temperature of Chassis :

5°C to 45°C (W/HDD)/0°C to 50°C (W/CF card only)

Real-Time Clock and Non-Volatile RAM

The FX5405 contains a real-time clock compartment that maintains the date and time in addition to storing configuration information about the computer system. It contains 14 bytes of clock and control registers and 114 bytes of general purpose RAM. Because of the use of CMOS technology, it consumes very little power and can be maintained for long periods of time using an internal Lithium battery. The contents of each byte in the CMOS RAM are listed below:

Address	Description
00	Seconds
01	Second alarm
02	Minutes
03	Minute alarm
04	Hours
05	Hour alarm
06	Day of week
07	Date of month
08	Month
09	Year
0A	Status register A
0B	Status register B

Address	Description
0C	Status register C
0D	Status register D
0E	Diagnostic status byte
0F	Shutdown status byte
10	Diskette drive type byte, drive A and B
11	Fixed disk type byte, drive C
12	Fixed disk type byte, drive D
13	Reserved
14	Equipment byte
15	Low base memory byte
16	High base memory byte
17	Low expansion memory byte
18	High expansion memory byte
19-2D	Reserved
2E-2F	2-byte CMOS checksum
30	Low actual expansion memory byte
31	High actual expansion memory byte
32	Date century byte
33	Information flags (set during power on)
34-7F	Reserved for system BIOS

CMOS RAM Map

Register	Description
00h -10h	Standard AT-compatible RTC and Status and Status Register data definitions
11h – 13h	Varies
14h	<p>Equipment</p> <p>Bits 7-6 Number of Floppy Drives 00 1 Drive 01 2 Drives</p> <p>Bits 5-4 Monitor Type 00 Not CGA or MDA 01 40x25 CGA 01 2 Drives 80x25 CGA</p> <p>Bits 3 Display Enabled 0 Disabled 1 Enabled</p> <p>Bit 2 Keyboard Enabled 00 Not CGA or MDA 01 40x25 CGA 01 2 Drives 80x25 CGA</p> <p>Bit 1 Math Coprocessor Installed 0 Absent 1 Present</p> <p>Bit 0 Floppy Drive Installed 0 Disabled 1 Enabled</p>
15h	Base Memory (in 1KB increments), Low Byte
16h	Base Memory (in 1KB increments), High Byte
17h	IBM-compatible memory (in 1KB increments), Low Byte
18h	IBM-compatible memory (in 1KB increments), High Byte (max 15 MB)
19h-2Dh	Varies
2Eh	Standard CMOS RAM checksum, high byte
2Fh	Standard CMOS RAM checksum, low byte
30h	IBM-compatible Extended Memory, Low Byte (POST) in KB
31h	IBM-compatible Extended Memory, High Byte (POST) in KB
32h	Century Byte
33h	Reserved. Do not use
34h	Reserved. Do not use
35h	Low byte of extended memory (POST) in 64 KB
36h	High byte of extended memory (POST) in 64 KB
37h-3Dh	Varies
3Eh	Extended CMOS Checksum, Low Byte (including 34h-3Dh)
3Fh	Extended CMOS Checksum, High Byte (including 34h-3Dh)

I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses, which also becomes the identity of the device. There is a total of 1K-port address space available. The following table lists the I/O port addresses used on the Industrial CPU Card.

Address	Device Description
000h - 01Fh	DMA Controller #1
020h - 03Fh	Interrupt Controller #1
040h - 05Fh	Timer
060h - 06Fh	Keyboard Controller
070h - 071h	Real Time Clock, NMI
078h - 07Bh	Reserved
080h - 09Fh	DMA Page Register
0A0h - 0BFh	Interrupt Controller #2
0C0h - 0DFh	DMA Controller #2
0F0h	Clear Math Coprocessor Busy Signal
0F1h	Reset Math Coprocessor
1F0h - 1F7h	IDE Interface
2F8h - 2FFh	Serial Port #2(COM2)
2B0 - 2DF	Graphics adapter Controller
300h - 302h	CANBUS
360 - 36F	Network Ports
3B0 - 3BF	Monochrome & Printer adapter
3C0 - 3CF	EGA adapter
3D0 - 3DF	CGA adapter
3F0h - 3F7h	Floppy Disk Controller
3F8h - 3FFh	Serial Port #1(COM1)

Interrupt Request Lines (IRQ)

There are a total of 15 IRQ lines available on the Industrial CPU Card. Peripheral devices use interrupt request lines to notify CPU for the service required. The following table shows the IRQ used by the devices on the Industrial CPU Card.

Level	Function
IRQ0	System Timer Output
IRQ1	Keyboard
IRQ2	Interrupt Cascade
IRQ3	Reserved
IRQ4	Serial Port #1
IRQ5	USB#0
IRQ6	Reserved
IRQ7	USB#2
IRQ8	Real Time Clock
IRQ9	SM-BUS
IRQ10	USB#1
IRQ11	CAN
IRQ12	USB#3/PS2 Mouse
IRQ13	FPU
IRQ14	Primary IDE
IRQ15	Secondary IDE (CF)

DMA Channel Map

The equivalents of two 8237A DMA controllers are implemented in the FX5405 board. Each controller is a four-channel DMA device that will generate the memory addresses and control signals necessary to transfer information directly between a peripheral device and memory. This allows high speed information transfer with less CPU intervention. The two DMA controllers are internally cascaded to provide four DMA channels for transfers to 8-bit peripherals (DMA1) and three channels for transfers to 16-bit peripherals (DMA2). DMA2 channel 0 provides the cascade interconnection between the two DMA devices, thereby maintaining IBM PC/AT compatibility.

The following is the system information of DMA channels:

DMA Controller 1	DMA Controller 2
Channel 0: Spare	Channel 4: Cascade for controller 1
Channel 1: Reserved for IBM SDLC	Channel 5: Spare
Channel 2: Diskette adapter	Channel 6: Spare
Channel 3: Spare	Channel 7: Spare

Serial Ports

The ACEs (Asynchronous Communication Elements ACE1 to ACE2) are used to convert parallel data to a serial format on the transmit side and convert serial data to parallel on the receiver side. The serial format, in order of transmission and reception, is a start bit, followed by five to eight data bits, a parity bit (if programmed) and one, one and half (five-bit format only) or two stop bits. The ACEs are capable of handling divisors of 1 to 65535, and produce a 16x clock for driving the internal transmitter logic.

Provisions are also included to use this 16x clock to drive the receiver logic, also included in the ACE a completed MODEM control capability, and a processor interrupt system that may be software tailored to the computing time required to handle the communications link.

The following table is a summary of each ACE accessible register

DLAB	Port Address	Register
0	Base + 0	Receiver buffer (read)
		Transmitter holding register (write)
0	Base + 1	Interrupt enable
X	Base + 2	Interrupt identification (read only)
X	Base + 3	Line control
X	Base + 4	MODEM control
X	Base + 5	Line status
X	Base + 6	MODEM status
X	Base + 7	Scratched register
1	Base + 0	Divisor latch (least significant byte)
1	Base + 1	Divisor latch (most significant byte)

➤ **Receiver Buffer Register (RBR)**

Bit 0-7: Received data byte (Read Only)

➤ **Transmitter Holding Register (THR)**

Bit 0-7: Transmitter holding data byte (Write Only)

➤ **Interrupt Enable Register (IER)**

Bit 0: Enable Received Data Available Interrupt (ERBFI)

Bit 1: Enable Transmitter Holding Empty Interrupt (ETBEI)

Bit 2: Enable Receiver Line Status Interrupt (ELSI)

Bit 3: Enable MODEM Status Interrupt (EDSSI)

Bit 4: Must be 0

Bit 5: Must be 0

Bit 6: Must be 0

Bit 7: Must be 0

➤ **Interrupt Identification Register (IIR)**

Bit 0: "0" if Interrupt Pending

Bit 1: Interrupt ID Bit 0

Bit 2: Interrupt ID Bit 1

Bit 3: Must be 0

Bit 4: Must be 0

Bit 5: Must be 0

Bit 6: Must be 0

Bit 7: Must be 0

➤ **Line Control Register (LCR)**

Bit 0: Word Length Select Bit 0 (WLS0)

Bit 1: Word Length Select Bit 1 (WLS1)

WLS1	WLS0	Word Length
0	0	5 Bits
0	1	6 Bits
1	0	7 Bits
1	1	8 Bits

Bit 2: Number of Stop Bit (STB)

Bit 3: Parity Enable (PEN)

Bit 4: Even Parity Select (EPS)

Bit 5: Stick Parity

Bit 6: Set Break

Bit 7: Divisor Latch Access Bit (DLAB)

➤ **MODEM Control Register (MCR)**

Bit 0: Data Terminal Ready (DTR)

Bit 1: Request to Send (RTS)

Bit 2: Out 1 (OUT 1)

Bit 3: Out 2 (OUT 2)

Bit 4: Loop

Bit 5: Must be 0

Bit 6: Must be 0

Bit 7: Must be 0

➤ **Line Status Register (LSR)**

Bit 0: Data Ready (DR)

Bit 1: Overrun Error (OR)

Bit 2: Parity Error (PE)

Bit 3: Framing Error (FE)

Bit 4: Break Interrupt (BI)

Bit 5: Transmitter Holding Register Empty (THRE)

Bit 6: Transmitter Shift Register Empty (TSRE)

Bit 7: Must be 0

➤ **MODEM Status Register (MSR)**

Bit 0: Delta Clear to Send (DCTS)

Bit 1: Delta Data Set Ready (DDSR)

Bit 2: Training Edge Ring Indicator (TERI)

Bit 3: Delta Receive Line Signal Detect (DSLSD)

Bit 4: Clear to Send (CTS)

Bit 5: Data Set Ready (DSR)

Bit 6: Ring Indicator (RI)

Bit 7: Received Line Signal Detect (RSLD)

➤ **Divisor Latch (LS, MS)**


	LS	MS
Bit 0:	Bit 0	Bit 8
Bit 1:	Bit 1	Bit 9
Bit 2:	Bit 2	Bit 10
Bit 3:	Bit 3	Bit 11
Bit 4:	Bit 4	Bit 12
Bit 5:	Bit 5	Bit 13
Bit 6:	Bit 6	Bit 14
Bit 7:	Bit 7	Bit 15

Desired Baud Rate	Divisor Used to Generate 16x Clock
300	384
600	192
1200	96
1800	64
2400	48
3600	32
4800	24
9600	12
14400	8
19200	6
28800	4
38400	3
57600	2
115200	1

Appendix

Dimension

a. FX5405



c. FX5404K1 universal fixers

