

IPC Solution
Website: <http://www.fabiatech.com>
Email: support@fabiatech.com

FB-2330 Disk Size All-In-One 386SX CPU Board Series User's Manual

MARCH 2005
Version: 1.5
Part Number: FB2330

Copyright

©Copyright 2001 by FablATech Corporation. The content of this publication may not be reproduced in any part or as a whole, transcribed, stored in a retrieval system, translated into any language, or transcribed in any form or by any means, electronic, mechanical, magnetic etc. or otherwise without the prior written permission of FablATech Corporation.

Disclaimer

FablATech makes no representation of warranties with respect to the contents of this publication. In an effort to continuously improve the product and add features, FablATech reserves the right to revise the publication or change specifications contained in it from time to time without prior notice of any kind from time to time. FablATech shall not be reliable for technical or editorial errors or omissions, which may occur in this document. FablATech shall not be reliable for any indirect, special, incidental or consequential damages resulting from the furnishing, performance, or use of this document.

Trademarks

Trademarks, brand names and products names mentioned in this publication are used for identification purpose only and are the properties of their respective owners.

Technical Support

If you have problems or difficulties in using the system board, or setting up the relevant devices, and software that are not explained in this manual, please contact our service engineer for service, or send email to support@fabiatech.com.

Returning Your Board For Service & Technical Support

If your board requires servicing, contact the dealer from whom you purchased the product for service information. You can help assure efficient servicing of your product by following these guidelines:

- ❑ A list of your name, address, telephone, facsimile number, or email address where you may be reached during the day
- ❑ Description of you peripheral attachments
- ❑ Description of you software (operating system, version, application software, etc.) and BIOS configuration
- ❑ Description of the symptoms (Extract wording any message)

For updated BIOS, drivers, manuals, or product information, please visit us at www.fabiatech.com

Static Electricity Precautions

Before removing the board from its anti-static bag, read this section about static electricity precautions.

Static electricity is a constant danger to the computer systems. The charge that can build up in your body may be more than sufficient to damage integrated circuits on any PC board. It is, therefore, important to observe basic precautions whenever you use or handle computer components. Although areas with humid climates are much less prone to static build-up, it is always the best to safeguard against accidents, which may result in expensive repairs. The following measures should generally be sufficient to protect your equipment from static discharge:

- ❑ Touch a grounded metal object to discharge the static electricity in your body (or ideally, wear a grounded wrist strap).
- ❑ When unpacking and handling the board or other system components, place all materials on an antic static surface.
- ❑ Be careful not to touch the components on the board, especially the “golden finger” connectors on the bottom of every board.

Table of contents

CHAPTER 1	OVERVIEW.....	1
1.1	INTRODUCTION	1
1.2	FEATURES.....	2
1.3	PACKING LIST.....	3
CHAPTER 2	SYSTEM CONTROLLERS.....	5
2.1	MICROPROCESSOR.....	5
2.2	DMA CONTROLLER.....	5
2.3	KEYBOARD CONTROLLER	6
2.4	INTERRUPT CONTROLLER.....	6
2.4.1	I/O PORT ADDRESS MAP	7
2.4.2	REAL-TIME CLOCK AND NON-VOLATILE RAM.....	8
2.4.3	TIMER.....	8
2.5	SERIAL PORTS.....	9
2.6	PARALLEL PORTS.....	11
CHAPTER 3	HARDWARE FEATURES.....	15
3.1	BOARD OVERVIEW	15
3.2	INDEX TO JUMPERS & CONNECTORS.....	16
3.3	SYSTEM SETTINGS.....	16
3.3.1	KEYBOARD/MOUSE CONNECTOR (CN1)	17
3.3.2	FLOPPY CONNECTOR (CN4: 20-PIN 2.0MM IDC)	18
3.3.3	PC/104 CONNECTOR (CN6 & CN7).....	18
3.3.4	HARD DISK (IDE) CONNECTOR (CN2)	22
3.3.5	RESET HEADER (J5)	23
3.3.6	PARALLEL PORT CONNECTOR (CN9 & CN10)	23
3.3.7	POWER CONNECTOR (J4)	24
3.3.8	SERIAL PORTS	25
3.3.9	UNIVERSAL SERIAL NUMBER (USN) ENABLE JUMPER (JP3)	28
3.3.10	RJ-45 CONNECTOR (CN5).....	28
3.3.11	BNC CONNECTOR (CN11)	29
3.3.12	CPU BASE CLOCK SELECT (JP7)	30
3.3.13	D.O.C/ SRAM SELECT (P1 & JP4).....	30
3.3.13.1	SRAM INSTALLATION (U10).....	31
	PROGRAMMING SSD (FLOPPY).....	31
	PROGRAMMING SSD (HDD)	32
3.3.13.2	D.O.C. INSTALLATION (U10).....	33
3.3.14	EXTERNAL BATTERY HEAD (J3)	34
3.3.15	LED INDICATORS	34
CHAPTER 4	CRT/LCD FLAT PANEL DISPLAY.....	35
4.1	LCD FLAT PANEL DISPLAYS	35
4.2	CRT & LCD DISPLAY.....	36
4.2.1	CRT CONNECTOR (DB1)	36
4.2.2	LCD CONNECTOR AND JUMPER SETTINGS (CN3 & JP1)	36
CHAPTER 5	INSTALLATION	39
5.1	INSTALLATION PROCEDURES	39
5.2	CD ROM.....	40
5.2.1	VGA DRIVER FOR WIN3.1	40
5.2.3	LAN UTILITY	41
5.3	WATCHDOG TIMER.....	41
5.3.1	WATCHDOG TIMER SETTING	41
5.3.2	WATCHDOG ENABLED/DISABLED - INDEX 37H	42
5.3.3	SELECT WATCHDOG REPORT SIGNAL - INDEX 38H.....	42
5.3.4	TIMEOUT STATUS & RESET WATCHDOG - INDEX 3CH.....	43

5.3.5 PROGRAMMING WATCHDOG - BASIC OPERATION	43
5.4 PROGRAMMING RS-485	45
CHAPTER 6 BIOS SETUP	47
6.1 BIOS SETUP OVERVIEW	47
6.2 STANDARD CMOS SETUP	49
6.3 ADVANCED CMOS SETUP	51
6.4 ADVANCED CHIPSET SETUP	55
6.5 PERIPHERAL SETUP	57
6.6 AUTO-DETECT HARD DISKS	59
6.7 PASSWORD SETTING	59
6.7.1 SETTING PASSWORD	59
6.7.2 PASSWORD CHECKING	59
6.8 LOAD DEFAULT SETTINGS	60
6.8.1 AUTO CONFIGURATION WITH OPTIMAL SETTINGS	60
6.8.2 AUTO CONFIGURATION WITH FAIL SAFE SETTINGS	61
6.9 BIOS EXIT	62
6.9.1 SAVE SETTINGS AND EXIT	62
6.9.2 EXIT WITHOUT SAVING	63
6.10 BIOS UPDATE	64
APPENDIX	65
A. SPECIFICATIONS	65
B1. PLACEMENT	66
B2. DIMENSIONS	66
B2. DIMENSIONS	67
C1. SRAM MEMORY BANKS	68
D1. PROGRAMMING GPIO0 (1) - BASIC OPERATION	70

List of Figures

CHAPTER 1 OVERVIEW	1
1.1 INTRODUCTION	1
1.2 FEATURES.....	2
1.3 PACKING LIST.....	3
CHAPTER 2 SYSTEM CONTROLLERS	5
2.1 MICROPROCESSOR.....	5
2.2 DMA CONTROLLER.....	5
2.3 KEYBOARD CONTROLLER	6
2.4 INTERRUPT CONTROLLER	6
2.4.1 I/O PORT ADDRESS MAP	7
2.4.2 REAL-TIME CLOCK AND NON-VOLATILE RAM.....	8
2.4.3 TIMER.....	8
2.5 SERIAL PORTS.....	9
2.6 PARALLEL PORTS.....	11
CHAPTER 3 HARDWARE FEATURES	15
3.1 BOARD OVERVIEW	15
3.2 INDEX TO JUMPERS & CONNECTORS	16
3.3 SYSTEM SETTINGS.....	16
3.3.1 KEYBOARD/MOUSE CONNECTOR (CN1 & J1).....	17
3.3.3 PC/104 CONNECTOR (CN6 & CN7).....	18
3.3.4 HARD DISK (IDE) CONNECTOR (CN2)	22
3.3.5 RESET HEADER (J5)	23
3.3.6 PARALLEL PORT CONNECTOR (CN9 & CN10)	23
3.3.7 POWER CONNECTOR (J4)	24
3.3.8 SERIAL PORTS	25
3.3.9 UNIVERSAL SERIAL NUMBER (USN) ENABLE JUMPER (JP3)	28
3.3.10 RJ-45 CONNECTOR (CN5).....	28
3.3.11 CPU BASE CLOCK SELECT (JP7)	30
3.3.12 D.O.C/ SRAM SELECT (P1 & JP4).....	30
3.3.1.1 SRAM Installation (U10)	31
PROGRAMMING SSD (FLOPPY)	31
PROGRAMMING SSD (HDD)	32
3.3.1.2 D.O.C. Installation (U10)	33
3.3.13 LED INDICATORS	34
CHAPTER 4 CRT/LCD FLAT PANEL DISPLAY	35
4.1 LCD FLAT PANEL DISPLAYS	35
4.2 CRT & LCD DISPLAY.....	36
4.2.1 CRT CONNECTOR (DB1)	36
4.2.2 LCD CONNECTOR AND JUMPER SETTINGS (CN3 & JP1)	36
CHAPTER 5 INSTALLATION	39
5.1 INSTALLATION PROCEDURES	39
5.2 CD ROM.....	40
5.2.1 VGA DRIVER FOR WIN3.1	40
5.2.3 LAN UTILITY	41
5.3 WATCHDOG TIMER.....	41
5.3.1 WATCHDOG TIMER SETTING	41
5.3.2 WATCHDOG ENABLED/DISABLED - INDEX 37H	42
5.3.3 SELECT WATCHDOG REPORT SIGNAL - INDEX 38H.....	42
5.3.4 TIMEOUT STATUS & RESET WATCHDOG - INDEX 3CH.....	43
5.3.5 PROGRAMMING WATCHDOG - BASIC OPERATION	43
5.4 PROGRAMMING RS-485.....	45

CHAPTER 6	BIOS SETUP	47
6.1	BIOS SETUP OVERVIEW	47
6.2	STANDARD CMOS SETUP.....	49
6.3	ADVANCED CMOS SETUP	51
6.4	ADVANCED CHIPSET SETUP	55
6.5	PERIPHERAL SETUP	57
6.6	AUTO-DETECT HARD DISKS	59
6.7	PASSWORD SETTING.....	59
6.7.1	SETTING PASSWORD	59
6.7.2	PASSWORD CHECKING.....	59
6.8	LOAD DEFAULT SETTINGS.....	60
6.8.1	AUTO CONFIGURATION WITH OPTIMAL SETTINGS	60
6.8.2	AUTO CONFIGURATION WITH FAIL SAFE SETTINGS	61
6.9	BIOS EXIT	62
6.9.1	SAVE SETTINGS AND EXIT	62
6.9.2	EXIT WITHOUT SAVING	63
6.10	BIOS UPDATE.....	64
APPENDIX	65
A.	SPECIFICATIONS.....	65
B1.	PLACEMENT.....	66
B2.	DIMENSIONS.....	67

List of Tables

Table 2-1 DMA Channel Controller	5
Table 2-2 Interrupt Controller.....	6
Table 2-3 I/O Port Address Map.....	7
Table 2-4 Real-Time Clock & Non-Volatile RAM	8
Table 2-5 ACE Accessible Registers.....	9
Table 2-6 Serial Port Divisor Latch	11
Table 2-7 Registers' Address	11
Table 3-1 Pin Assignments of CN1.....	17
Table 3-2 Floppy Connector Pin Assignments.....	18
Table 3-3 CN7: 64-Pin PC/104 Connector Bus A & B.....	19
Table 3-4 CN6: 40-Pin PC/104 Connector Bus C & D.....	20
Table 3-5 PC/104 ISA Pin Assignments.....	21
Table 3-6 CN2: Hard Disk (IDE) Connector	22
Table 3-7 Parallel Port Pin Assignments	24
Table 3-8 Phone Jack Connector Pin Assignments	26
Table 3-9 RS-232C Header Pin Assignments	26
Table 3-10 Serial Port RS-232 COM A Pin Assignments.....	27
Table 3-11 Serial Port RS-232 COM B & C Pin Assignments	27
Table 3-12 Serial Port RS-232/RS-485 COM D Pin Assignments.....	28
Table 3-13 USN Jumper Setting	28
Table 3-14 RJ-45 Pin Assignments.....	29
Table 4-1 LCD Connector Pin Assignments.....	37

CHAPTER 1 OVERVIEW

This chapter provides an overview of your system features and capabilities. The following topics are covered:

- Introduction
- Packing List
- Features

1.1 INTRODUCTION

The FB2330 is a mature and well-developed 3.5" disk size 386SX board. It provides much greater performance such as support for onboard 8MB DRAM, one RS-232C/485 port, four RS-232C ports, 2 parallel ports and one socket for the DiskOnChip® with up to 288 MB memory capacity.

The FB2330 also comes with a programmable Watchdog timer and other typical interfaces. It is excellent for embedded systems, MMI's, workstations, medical applications or POS/POI systems. As well, an RS-232C/485 port provides the remote control.

Especially, the FB2330 has 512 KB VRAM on board and uses the C&T 65545 Chipset, to support a wide range of LCD panels.

1.2 FEATURES

The system provides a number of special features that enhance its reliability, ensure its availability, and improve its expansion capabilities, as well as its hardware structure.

- Up to 40 MHz 386SX single board computer.
- PC/104 expansion bus.
- 8 MB EDO RAM on-board.
- 10Base-T NE2000 compatible network.
- CRT and LCD interface, 512K VRAM.
- Parallel port, floppy and IDE Interface.
- 4 serial ports with power output. RS-485 is also available.
- PS/2 compatible keyboard interface.
- E2KEY function for safe CMOS data keeping. (Optional)
- On-board buzzer and LED indicator.
- Flash BIOS with easy upgrade utility.
- Software programmable watchdog timer.
- Provides 1 socket for up to 288 MB DiskOnChip or 512KB SRAM disk.
- DS2401 silicon serial number and I/O drive lines. (Optional)
- Low power consumption, +5V only, 2.0A maximum (based on 40 MHz)
- EMI Considered on every output signals.
- 3.5" disk form factor, 145 mm x 102 mm

1.3 PACKING LIST

The following accessories are included in the package. Before you begin installing your FB2330 board, take a moment to make sure that they have been included inside the FB2330 package.

- 1 FB2330 all-in-one CPU board
- 1 44-pin hard disk drive interface cable
- 1 20-pin to 34-pin floppy drive interface cable
- 1 parallel port interface cable
- 4 serial port adapter cables (10-pin phone-jack to DB-9)
- 1 power adapter cable
- 1 CD includes necessary utility drivers, quick setting guide file, and this manual file
- A hard copy of User's quick setting guide

NOTE: *If any of the listed accessories is missing or damaged, please contact your dealer for immediate servicing.*

CHAPTER 2 SYSTEM CONTROLLERS

This chapter describes the major structure of the FB2330 CPU board. The following topics are covered:

- Microprocessor
 - DMA Controller
 - Keyboard Controller
 - Interrupt Controller
 - Serial Ports
 - Parallel Ports
-

2.1 MICROPROCESSOR

The FB2330 uses the ALI M6117 CPU; it is designed to perform systems like Intel's 386SX system with deep green features.

The 386SX core is the same as M1386SX of Acer Labs. Inc. and 100% object code compatible with the Intel 386SX microprocessor. System manufacturers can provide 386 CPU based systems optimized for both cost and size. Instruction pipelining and high bus bandwidth ensure short average instruction execution time and high system throughput. Furthermore, it can keep the state internally from charge leakage while external clock to the core is stopped without storing the data in registers. The power consumption here is almost zero until the clock stops. The internal structure of this core is 32-bit data and address bus with very low supply current. Real mode as well as Protected mode are available and can run MS-DOS /MS-Windows.

2.2 DMA CONTROLLER

The equivalent of two 8237A DMA controllers are implemented in the FB2330 board. Each controller is a four-channel DMA device that will generate the memory addresses and control signals necessary to transfer information directly between a peripheral device and memory. This allows high speeding information transfer with less CPU intervention. The two DMA controllers are internally cascaded to provide four DMA channels for transfers to 8-bit peripherals (DMA1) and three channels for transfers to 16-bit peripherals (DMA2). DMA2 channel 0 provides the cascade interconnection between the two DMA devices, thereby maintaining IBM PC/AT compatibility.

The following is the system information of DMA channels:

DMA Controller 1	DMA Controller 2
Channel 0: Spare	Channel 4: Cascade for controller 1
Channel 1: Reserved for IBM SDLC	Channel 5: Spare
Channel 2: Diskette adapter	Channel 6: Spare
Channel 3: Spare	Channel 7: Spare

Table 2-1 DMA Channel Controller

2.3 KEYBOARD CONTROLLER

The 8042 processor is programmed to support the keyboard serial interface. The keyboard controller receives serial data from the keyboard, checks its parity, translates scan codes, and presents it to the system as a byte data in its output buffer. The controller can interrupt the system when data is placed in its output buffer, or wait for the system to poll its status register to determine when data is available.

Data can be written to the keyboard by writing data to the output buffer of the keyboard controller.

Each byte of data is sent to the keyboard controller in series with an odd parity bit automatically inserted. The keyboard controller is required to acknowledge all data transmissions. Therefore, another byte of data will not be sent to keyboard controller until acknowledgment is received for the previous byte sent. The "output buffer full" interruption may be used for both send-and-receive routines.

2.4 INTERRUPT CONTROLLER

The equivalent of two 8259 Programmable Interrupt Controllers (PIC) are included on the FB2330 board. They accept requests from peripherals, resolve priorities on pending interrupts in service, issue interrupt requests to the CPU, and provide vectors which are used as acceptance indices by the CPU to determine which interrupt service routine to execute.

The following table contains the system information of hardware interrupt priorities:

System Interrupt	IRQ	Function	Priority
08h	IRQ 0	System timer (Timer Channel 0 output)	1
09h	IRQ 1	Keyboard controller output buffer full interrupt	2
0Ah	IRQ 2	Cascade from second programmable interrupt	-
0Bh	IRQ 3	COM2	10
0Ch	IRQ 4	COM1	11
0Dh	IRQ 5	Parallel port 2	12
0Eh	IRQ 6	Floppy diskette adapter	13
0Fh	IRQ 7	Parallel port 1	14
70h	IRQ 8	Real Time Cock	15
71h	IRQ 9	COM4	3
72h	IRQ 10	LAN adapter	4
73h	IRQ 11	COM3	5
74h	IRQ 12	Reserved for PS/2 mouse	6
75h	IRQ 13	Math coprocessor	7
76h	IRQ 14	Hard diskette adapter	8
77h	IRQ 15	Reserved for Watchdog	9

Table 2-2 Interrupt Controller

2.4.1 I/O Port Address Map

Hex Range	Device
000-01F	DMA controller 1
020-021	Interrupt controller 1
022-023	ALI M6117 chipset address
040-04F	Timer 1
050-05F	Timer 2
060-06F	8042 keyboard/controller
070-071	Real-time clock (RTC), non-maskable interrupt (NMI)
080-09F	DMA page registers
0A0-0A1	Interrupt controller 2
0C0-0DF	DMA controller 2
0F0	Clear Math Co-processor
0F1	Reset Math Co-processor
0F8-0FF	Math Co-processor
170-178	Fixed disk 1
1F0-1F8	Fixed disk 0
201	Game port
208-20A	EMS register 0
218-21A	EMS register 1
278-27F	Parallel printer port 2 (LPT 2)
2E8-2EF	Serial port 4 (COM 4)
2F8-2FF	Serial port 2 (COM 2)
300-31F	Prototype card/streaming type adapter
320-33F	LAN adapter
378-37F	Parallel printer port 1 (LPT 1)
380-38F	SDLC, bisynchronous 2
3A0-3AF	Bisynchronous 1
3B0-3BF	Monochrome display and printer port 3 (LPT 3)
3C0-3CF	EGA/VGA adapter
3D0-3DF	Color/graphics monitor adapter
3E8-3EF	Serial port 3 (COM 3)
3F0-3F7	Diskette controller
3F8-3FF	Serial port 1 (COM 1)

Table 2-3 I/O Port Address Map

2.4.2 Real-Time Clock and Non-Volatile RAM

The FB2330 contains a real-time clock compartment that maintains the date and time in addition to storing configuration information about the computer system. It contains 14 bytes of clock and control registers and 114 bytes of general purpose RAM. Because of the use of CMOS technology, it consumes very little power and can be maintained for long periods of time using an internal Lithium battery. The contents of each byte in the CMOS RAM are listed below:

Address	Description
00	Seconds
01	Second alarm
02	Minutes
03	Minute alarm
04	Hours
05	Hour alarm
06	Day of week
07	Date of month
08	Month
09	Year
0A	Status register A
0B	Status register B
0C	Status register C
0D	Status register D
0E	Diagnostic status byte
0F	Shutdown status byte
10	Diskette drive type byte, drive A and B
11	Fixed disk type byte, drive C
12	Fixed disk type byte, drive D
13	Reserved
14	Equipment byte
15	Low base memory byte
16	High base memory byte
17	Low expansion memory byte
18	High expansion memory byte
19-2D	Reserved
2E-2F	2-byte CMOS checksum
30	Low actual expansion memory byte
31	High actual expansion memory byte
32	Date century byte
33	Information flags (set during power on)
34-7F	Reserved for system BIOS

Table 2-4 Real-Time Clock & Non-Volatile RAM

2.4.3 Timer

The FB2330 provides three programmable timers, each with a timing frequency of 1.19 MHz.

Timer 0 The output of this timer is tied to interrupt request 0. (IRQ 0)

Timer 1 This timer is used to trigger memory refresh cycles.

Timer 2 This timer provides the speaker tone. Application programs can load different counts into this timer to generate various sound frequencies.

2.5 SERIAL PORTS

The ACEs (Asynchronous Communication Elements ACE1 to ACE4) are used to convert parallel data to a serial format on the transmit side and convert serial data to parallel on the receiver side. The serial format, in order of transmission and reception, is a start bit, followed by five to eight data bits, a parity bit (if programmed) and one, one and half (five-bit format only) or two stop bits. The ACEs are capable of handling divisors of 1 to 65535, and produce a 16x clock for driving the internal transmitter logic.

Provisions are also included to use this 16x clock to drive the receiver logic. Also included in the ACE is a completed MODEM control capability, and a processor interrupt system that may be software tailored to the computing time required to handle the communications link.

The following table is a summary of each ACE accessible register

DLAB	Port Address	Register
0	Base + 0	Receiver buffer (read)
		Transmitter holding register (write)
0	Base + 1	Interrupt enable
X	Base + 2	Interrupt identification (read only)
X	Base + 3	Line control
X	Base + 4	MODEM control
X	Base + 5	Line status
X	Base + 6	MODEM status
X	Base + 7	Scratched register
1	Base + 0	Divisor latch (least significant byte)
1	Base + 1	Divisor latch (most significant byte)

Table 2-5 ACE Accessible Registers

- **Receiver Buffer Register (RBR)**
Bit 0-7: Received data byte (Read Only)
- **Transmitter Holding Register (THR)**
Bit 0-7: Transmitter holding data byte (Write Only)
- **Interrupt Enable Register (IER)**
Bit 0: Enable Received Data Available Interrupt (ERBFI)
Bit 1: Enable Transmitter Holding Empty Interrupt (ETBEI)
Bit 2: Enable Receiver Line Status Interrupt (ELSI)
Bit 3: Enable MODEM Status Interrupt (EDSSI)
Bit 4: Must be 0
Bit 5: Must be 0
Bit 6: Must be 0
Bit 7: Must be 0
- **Interrupt Identification Register (IIR)**
Bit 0: "0" if Interrupt Pending
Bit 1: Interrupt ID Bit 0
Bit 2: Interrupt ID Bit 1
Bit 3: Must be 0
Bit 4: Must be 0
Bit 5: Must be 0
Bit 6: Must be 0

Bit 7: Must be 0

➤ **Line Control Register (LCR)**

Bit 0: Word Length Select Bit 0 (WLS0)

Bit 1: Word Length Select Bit 1 (WLS1)

WLS1	WLS0	Word Length
0	0	5 Bits
0	1	6 Bits
1	0	7 Bits
1	1	8 Bits

Bit 2: Number of Stop Bit (STB)

Bit 3: Parity Enable (PEN)

Bit 4: Even Parity Select (EPS)

Bit 5: Stick Parity

Bit 6: Set Break

Bit 7: Divisor Latch Access Bit (DLAB)

➤ **MODEM Control Register (MCR)**

Bit 0: Data Terminal Ready (DTR)

Bit 1: Request to Send (RTS)

Bit 2: Out 1 (OUT 1)

Bit 3: Out 2 (OUT 2)

Bit 4: Loop

Bit 5: Must be 0

Bit 6: Must be 0

Bit 7: Must be 0

➤ **Line Status Register (LSR)**

Bit 0: Data Ready (DR)

Bit 1: Overrun Error (OR)

Bit 2: Parity Error (PE)

Bit 3: Framing Error (FE)

Bit 4: Break Interrupt (BI)

Bit 5: Transmitter Holding Register Empty (THRE)

Bit 6: Transmitter Shift Register Empty (TSRE)

Bit 7: Must be 0

➤ **MODEM Status Register (MSR)**

Bit 0: Delta Clear to Send (DCTS)

Bit 1: Delta Data Set Ready (DDSR)

Bit 2: Training Edge Ring Indicator (TERI)

Bit 3: Delta Receive Line Signal Detect (DSLSD)

Bit 4: Clear to Send (CTS)

Bit 5: Data Set Ready (DSR)

Bit 6: Ring Indicator (RI)

Bit 7: Received Line Signal Detect (RSLD)

➤ *Divisor Latch (LS, MS)*

	LS	MS
Bit 0:	Bit 0	Bit 8
Bit 1:	Bit 1	Bit 9
Bit 2:	Bit 2	Bit 10
Bit 3:	Bit 3	Bit 11
Bit 4:	Bit 4	Bit 12
Bit 5:	Bit 5	Bit 13
Bit 6:	Bit 6	Bit 14
Bit 7:	Bit 7	Bit 15

Desired Baud Rate	Divisor Used to Generate 16x Clock
300	384
600	192
1200	96
1800	64
2400	48
3600	32
4800	24
9600	12
14400	8
19200	6
28800	4
38400	3
57600	2
115200	1

Table 2-6 Serial Port Divisor Latch

2.6 PARALLEL PORTS

➤ *Register Address*

Port Address	Read/Write	Register
Base + 0	Write	Output data
Base + 0	Read	Input data
Base + 1	Read	Printer status buffer
Base + 2	Write	Printer control latch

Table 2-7 Registers' Address

➤ *Printer Interface Logic*

The parallel portion of the SMC37C669 makes the attachment of various devices that accept eight bits of parallel data at standard TTL level.

➤ *Data Swapper*

The system microprocessor can read the contents of the printer's Data Latch through the Data Swapper by reading the Data Swapper address.

➤ **Printer Status Buffer**

The system microprocessor can read the printer status by reading the address of the Printer Status Buffer. The bit definitions are described below:




Figure 2-1 Printer Status Buffer

NOTE: X represents not used.

Bit 7: This signal may become active during data entry, when the printer is off-line during printing, or when the print head is changing position or in an error state. When Bit 7 is active, the printer is busy and can not accept data.

Bit 6: This bit represents the current state of the printer's ACK signal. A 0 means the printer has received the character and is ready to accept another. Normally, this signal will be active for approximately 5 microseconds before receiving a BUSY message stops.

Bit 5: A 1 means the printer has detected the end of the paper.

Bit 4: A 1 means the printer is selected.

Bit 3: A 0 means the printer has encountered an error condition.

➤ **Printer Control Latch & Printer Control Swapper**

The system microprocessor can read the contents of the printer control latch by reading the address of printer control swapper. Bit definitions are as follows:




Figure 2-2 Printer Control Bit Definitions

NOTE: *X represents not used.*

- Bit 5: Direction control bit. When logic 1, the output buffers in the parallel port are disabled allowing data driven from external sources to be read; when logic 0, they work as a printer port. This bit is write-only.
- Bit 4: A 1 in this position allows an interrupt to occur when ACK changes from low state to high state.
- Bit 3: A 1 in this bit position selects the printer.
- Bit 2: A 0 starts the printer (50 microseconds pulse, minimum).
- Bit 1: A 1 causes the printer to line-feed after a line is printed.
- Bit 0: A 0.5 microsecond minimum highly active pulse clocks data into the printer. Valid data must be present for a minimum of 0.5 microseconds before and after the strobe pulse.

CHAPTER 3 HARDWARE FEATURES

This section describes the pin assignments for system's external connectors and the jumper settings.

- Board Overview
- System Setting

3.1 BOARD OVERVIEW

The FB2330 is an all-in-one, half-size, 386SX CPU board. This section provides hardware jumper settings, the connectors' locations, and the pin assignment.




Figure 3-1 System Components Overview

3.2 INDEX TO JUMPERS & CONNECTORS

The following lists the jumper and connector functions for reference.

Label	Function
CN1	Mini-Din keyboard/mouse connector
CN2	44-pin hard disk connector
CN3	44-pin LCD connector
CN4	20-pin floppy connector
CN5	RJ45 connector
CN6	40-pin PC/104 connector Bus C&D
CN7	64-pin PC/104 connector A&B
CN8	4* EIA RS-232C Phone jacks
CN9/CN10	26-pin parallel ports
DB1	15-pin CRT connector
J3	2- pin External battery for SRAM
J4	4-pin power header
J5	2 pin reset header
J6/J7	COM3/COM4 RS-232C headers
JP2	M/DE signal select for TFT LCD
JP3	Universal Serial Number enable jumper
JP5/JP6	Power output select jumpers
JP7	CPU base clock select
JP8	Terminator on/off
JP4/P1	D.O.C./SRAM select
P2/P3	COM4 RS232C/ RS-485 select

3.3 SYSTEM SETTINGS

Jumper pins allow you to set specific system parameters. Set them by changing the pin location of jumper blocks. (A jumper block is a small plastic-encased conductor [shorting plug] that slips over the pins.) To change a jumper setting, remove the jumper from its current location with your fingers or small needle-nosed pliers. Place the jumper over the two pins designated for the desired setting. Press the jumper evenly onto the pins. Be careful not to bend the pins.

We will show the locations of the FB2330 jumper pins, and the factory-default settings.

CAUTION: Do not touch any electronic component unless you are safely grounded. Wear a grounded wrist strap or touch an exposed metal part of the system unit chassis. The static discharges from your fingers can permanently damage the electronic components.

3.3.1 Keyboard/Mouse Connector (CN1)

(1) 6-Pin Mini DIN Keyboard/Mouse Connector (CN1)

The keyboard/mouse connector is a Mini-DIN 6-pin connector, labeled CN1. It is a PS/2 type connector and is also used for a standard IBM-compatible keyboard with a keyboard adapter cable. The pin assignments for the PS/2 port connector are as follows.




Figure 3-2 Front View of CN1 Mini-Din Connector

Pin	Signal
1	Keyboard Data
2	Mouse Data
3	Ground
4	VCC
5	Keyboard Clock
6	Mouse Clock

Table 3-1 Pin Assignments of CN1

3.3.2 Floppy Connector (CN4: 20-pin 2.0mm IDC)

The included floppy drive interface cable is used to transfer 20-pin connector into standard 34-pin connector. The following table shows signal connections between 20-pin & 34-pin connectors.





Figure 3-3 CN4: Floppy Connector

20-pin	Signal	34-pin	20-pin	Signal	34-pin
1	Drive Enable A	2	11	-Write Data	22
2	-Index	8	12	Ground	23
3	-Select A	12	13	-Write Enable	24
4	Ground	11	14	-Track 0	26
5	-Motor A	16	15	-Write Protect	28
6	- Select B	14	16	Ground	29
7	-Motor B	10	17	-Read Data	30
8	Ground	9	18	-Head	32
9	-Direction	18	19	-Disk Change	34
10	-Step	20	20	Ground	31
-	-	-	-	No connection	Others

Table 3-2 Floppy Connector Pin Assignments

3.3.3 PC/104 Connector (CN6 & CN7)

(1) 64 Pin PC/104 Connector Bus A & B (CN7)



CN7 - BUS A & B

Figure 3-4 CN7: 64-Pin PC/104 Connector Bus A & B

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	-IOCHK	33	SA14	2	Ground	34	-DACK1
3	SD7	35	SA13	4	RSTDRV	36	DRQ1
5	SD6	37	SA12	6	+5V	38	-REFSH
7	SD5	39	SA11	8	IRQ9	40	BUSCLK
9	SD4	41	SA10	10	-5V (*1)	42	IRQ7
11	SD3	43	SA9	12	DRQ2	44	IRQ6
13	SD2	45	SA8	14	-12V (*1)	46	IRQ5
15	SD1	47	SA7	16	-ZWS	48	IRQ4
17	SD0	49	SA6	18	+12V	50	IRQ3
19	IORDY	51	SA5	20	Key1	52	-DACK2
21	AEN	53	SA4	22	-MEMW	54	TC
23	SA19	55	SA3	24	-MEMR	56	ALE
25	SA18	57	SA2	26	-IOW	58	+5V
27	SA17	59	SA1	28	-IOR	60	OSC
29	SA16	61	SA0	30	-DACK3	62	Ground
31	SA15	63	Ground	32	DRQ3	64	Ground

Table 3-3 CN7: 64-Pin PC/104 Connector Bus A & B

NOTE: Power input, +5V, -5V, +12V, or -12V for Pin 10 & Pin14 is supplied from the system power connected to the power connector.

(2) 40 Pin PC/104 Connector Bus C & D (CN6)




Figure 3-5 CN6: 40-Pin PC/104 Connector Bus C & D

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	Ground	21	MEMWR16	2	Ground	22	-DACK5
3	-SBHE	23	SD8	4	-MEM16	24	DRQ5
5	LA23	25	SD9	6	-IO16	26	-DACK6
7	LA22	27	SD10	8	IRQ10	28	DRQ6
9	LA21	29	SD11	10	IRQ11	30	-DACK7
11	LA20	31	SD12	12	IRQ12	32	DRQ7
13	LA19	33	SD13	14	IRQ15	34	+5V
15	LA18	35	SD14	16	IRQ14	36	-MASTER
17	LA17	37	SD15	18	-DACK0	38	Ground
19	MEMRD16	39	Key2	20	DRQ0	40	Ground

Table 3-4 CN6: 40-Pin PC/104 Connector Bus C & D

(3) PC/104 (ISA) Signal Description

Name	Description
BUSCLK [Output]	The BUSCLK signal of the I/O channel is asynchronous to the CPU clock.
RSTDRV [Output]	This signal goes high during power-up, low line-voltage or hardware reset
SA0 - SA19 [Input / Output]	The System Address lines run from bit 0 to 19. They are latched onto the falling edge of "BALE"
LA17 - LA23 [Input/Output]	The Unlatched Address line run from bit 17 to 23
SD0 - SD15 [Input/Output]	System Data bit 0 to 15
ALE [Output]	The Buffered Address Latch Enable is used to latch SA0 – SA19 onto the falling edge. This signal is forced high during DMA cycles
-IOCHCK [Input]	The I/O Channel Check is an active low signal which indicates that a parity error exist on the I/O board
IORDY [Input, Open collector]	This signal lengthens the I/O, or memory read/write cycle, and should be held low with a valid address
IRQ 3-7, 9-12, 14, 15 [Input]	The Interrupt Request signal indicates I/O service request attention. They are prioritized in the following sequence: (Highest) IRQ 9, 10, 11, 12, 13, 15, 3, 4, 5, 6, 7 (Lowest)
-IOR [Input/Output]	The I/O Read signal is an active low signal which instructs the I/O device to drive its data onto the data bus
-IOW [Input/Output]	The I/O write signal is an active low signal which instructs the I/O device to read data from the data bus
-SMEMR [Output]	The System Memory Read is low while any of the low 1mega bytes of memory are being used
-MEMR 16 [Input/Output]	The Memory Read signal is low while any memory location is being read
-MEMW [Output]	The System Memory Write is low while any of the low 1mega bytes of memory is being written
-MEMW [Input/Output]	The Memory Write signal is low while any memory location is being written
DRQ 0-3, 5-7 [Input]	DMA Request channels 0 to 3 are for 8-bit data transfers. DMA Request channels 5 to 7 are for 16-bit data transfers. DMA request should be held high until the corresponding DMA has been completed. DMA request priority is in the following sequence:(Highest) DRQ 0, 1, 2, 3, 5, 6, 7 (Lowest)
-DACK 0-3, 5-7 [Output]	The DMA Acknowledges 0 to 3, 5 to 7 are the corresponding acknowledge signals for DRQ 0 to 3 and 5 to 7
AEN [output]	The DMA Address Enable is high when the DMA controller is driving the address bus. It is low when the CPU is driving the address bus
-REFSH [Input/Output]	This signal is used to indicate a memory refresh cycle and can be driven by the microprocessor on the I/O channel
TC [Output]	Terminal Count provides a pulse when the terminal count for any DMA channel is reached
-SBHE [Input/Output]	The System Bus High Enable indicates the high byte SD8 - SD15 on the data bus
-MASTER [Input]	The MASTER is the signal from the I/O processor which gains control as the master and should be held low for a maximum of 15 microseconds or system memory may be lost due to the lack of refresh
-MEM16 [Input,Open collector]	The Memory Chip Select 16 indicates that the present data transfer is a 1-wait state, 16-bit data memory operation
-IO16 [Input, Open collector]	The I/O Chip Select 16 indicates that the present data transfer is a 1-wait state, 16-bit data I/O operation
OSC [Output]	The Oscillator is a 14.31818 MHz signal
-ZWS [Input, Open collector]	The Zero Wait State indicates to the microprocessor that the present bus cycle can be completed without inserting additional wait cycle

Table 3-5 PC/104 ISA Pin Assignments

3.3.4 Hard Disk (IDE) Connector (CN2)

A 44-pin header type connector (CN2) is provided to interface with up to two embedded hard disk drives (IDE AT bus). This interface, through a 44-pin cable, allows the user to connect up to two drives in a "daisy chain" fashion. To enable or disable the hard disk controller, please use BIOS Setup program to select. The following table illustrates the pin assignments of the hard disk drive's 44-pin connector.




Figure 3-6 CN2: Hard Disk (IDE) Connector

Pin	Signal	Pin	Signal
1	-RESET	2	Ground
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	Ground	20	Ground
21	Not Used	22	Ground
23	-IOW A	24	Ground
25	-IOR A	26	Ground
27	-CHRDY A	28	DALE
29	Not Used	30	Ground
31	-IRQ 14	32	-IO16
33	SA 1	34	Not Used
35	SA 0	36	SA 2
37	CS 0	38	CS 1
39	HD LED A	40	Ground
41	VCC	42	VCC
43	Ground	44	Not Used

Table 3-6 CN2: Hard Disk (IDE) Connector

3.3.5 Reset Header (J5)

J5 is used to connect to an external reset switch. Shorting these two pins will reset the system.




Figure 3-7 J5: Reset Header

3.3.6 Parallel Port Connector (CN9 & CN10)

Use the included adapter cable to connect the 26-pin header type CN9 or CN10 connector. This adapter cable is mounted on a bracket and is included in your FB2330 package. The connector for the parallel port is a 25 pin D-type female connector. The following table shows signal connections between 26-pin & DB25 connectors. CN9 is parallel port 1 and CN10 is parallel port 2.




Figure 3-8 CN9 & CN10: Parallel Port Connectors

CN9&CN1 0	DB-25	Signal	CN9&CN1 0	DB-25	Signal
1	1	-STROBE	2	14	-AUTO FORM FEED
3	2	DATA 0	4	15	-ERROR
5	3	DATA 1	6	16	-INITIALIZE
7	4	DATA 2	8	17	-PRINTER SELECT IN
9	5	DATA 3	10	18	Ground
11	6	DATA 4	12	19	Ground
13	7	DATA 5	14	20	Ground
15	8	DATA 6	16	21	Ground
17	9	DATA 7	18	22	Ground
19	10	-ACKNOWLEDGE	20	23	Ground
21	11	BUSY	22	24	Ground
23	12	PAPER	24	25	Ground
25	13	PRINTER SELECT	26	--	No Used

Table 3-7 Parallel Port Pin Assignments

3.3.7 Power Connector (J4)

J4 is a 4-pin power connector. Using the J4, you can connect the power supply to the on board power connector for stand alone applications directly.





Figure 3-9 Power Connectors

NOTE: The FB2330 also provides an optional 8-pin power connector.

3.3.8 Serial Ports

➤ Power Output Select Jumpers (JP5 & JP6)

All four serial ports provide power output pin in their phone-jack connectors, but only COM port 1 & 2 have power select jumper. COM port 3 & 4 always supply VCC (+5V) to power output pin. Please use the proper adapter cable to attach the power



source.

Figure 3-10 Power Output Select

➤ RS-485 Jumper Select and Pin Definitions (P2/P3 & JP8)

Serial port 4 provides RS-485 function by adjusting P2 and P3 jumpers. P2 is a 2x3 jumper and P3 is a 1x3 jumper. When RS-485 mode is selected, the RS-485 signals use the same connector as RS-232C. JP8 is a terminator on/off jumper only for RS-485 mode.

The following figure and table guide you how to set up RS-485 serial port.




Figure 3-11 RS-485 Selection

Phone Jack	Signal
1	-
2	-
3	485-
4	-
5	485+
6	-
7	-
8	-
9	-
10	-

Table 3-8 Phone Jack Connector Pin Assignments

➤ **Extra RS-232C Headers (J6 & J7)**

Header J6 and J7 provide basic RS-232C signals of serial port 3 & port 4 respectively. They are used to interface with touch screen module or other internal connection usage.




Figure 3-12 J6 & J7 Positions

J6 (Serial Port 3)	Signal	J7 (Serial Port 4)	Signal
1	TXD3	1	TXD4
2	RXD3	2	RXD4
3	Ground	3	Ground

Table 3-9 RS-232C Header Pin Assignments

➤ **RS-232C Connector (CN8)**

There are four serial ports with EIA RS-232C interface on the FB2330. COM A, COM B and COM C use three on-board serial port Phone-Jack 10-pin female connector (CN8). To configure these four serial ports, enter the BIOS to set, and COM D can be used for RS-485 or RS-232C by adjusting the jumpers on P2 & P3.

The included serial port adapter cables are used to transfer 10-pin phone-jack connectors into standard DB9 connector. The following left table shows signal connections without power output and the right table shows signal connections with power output.

The pin assignments of the CN8 for serial port A, B; C & D are as follows:




Figure 3-13 CN8: RS-232C Connector

CN8-A	CN8-B	DB-9	Signal	CN8-A	CN8-B	DB-9	Signal
1	1	1	-DCD	2	2	8	-CTS
3	3	7	-RTS	4	4	6	-DSR
5	5	2	RXD	6	6	3	TXD
7	7	4	-DTR	8	8	9	-RI
9	9	5	GND	10	10		+5V /+12v

Table 3-10 Serial Port RS-232 COM A & B Pin Assignments

CN8-C	DB-9	Signal	CN8-C	DB-9	Signal
1	1	-DCD	2	8	-CTS
3	7	-RTS	4	6	-DSR
5	2	RXD	6	3	TXD
7	4	-DTR	8	9	-RI
9	5	Ground	10		+5V

Table 3-11 Serial Port RS-232 COM B & C Pin Assignments

CN8-D	DB-9	Signal	CN8-D	DB-9	Signal
1	1	-DCD	2	8	-CTS
3	7	-RTS / 485N+	4	6	-DSR
5	2	RXD	6	3	TXD
7	4	-DTR / 485N-	8	9	-RI
9	5	GND	10		+5V

Table 3-12 Serial Port RS-232/RS-485 COM D Pin Assignments

NOTE: cable without power output *NOTE: cable with power output*

3.3.9 Universal Serial Number (USN) Enable Jumper (JP3)

FB2330 uses –RTS and –CTS signals on serial port 4 to control the USN chip. If the USN function is enabled, you may not use full RS-232C signals on COM port 4. If COM port 4 is set as RS-485 mode or interface with touch screen module, you could enable both RS-485 communication/touch screen and USN function.




Table 3-13 USN Jumper Setting

3.3.10 RJ-45 Connector (CN5)

CN5 is a standard network RJ-45 port. The following table lists CN5 pin assignments.




Figure 3-14 CN5: RJ-45 Connector

PIN (CN5)	FUNCTION
1	TPTX+
2	TPTX -
3	TPRX+
4	Not Used
5	Not Used
6	TPRX -
7	Not Used
8	Not Used

Table 3-14 RJ-45 Pin Assignments

3.3.11 BNC CONNECTOR (CN11)

It is necessary to use the BNC adapter board (FB4616) and cable for attaching to CN11 connector. The following table lists the pin assignment of CN11.




Figure 3-15 CN12 to BNCFB4616 board Connector

CN11	Signal	CN11	Signal
1	LCD+	2	LCD-
3	VCC	4	GND
5	LRX+	6	LRX-
7	GND	8	BNCEN
9	LTPX+	10	LPTX-

Table 3-15 CN11 Pin Assignment

3.3.12 CPU Base Clock Select (JP7)

The CPU base clock (Input clock) is twice of its operation clock.




Figure 3-16 JP7: CPU Base Clock Select

3.3.13 D.O.C/ SRAM Select (P1 & JP4)

FB2330 provides SRAM storage solution. DOC and SRAM have different settings. Refer to the





Figure 3-17 DOC/SRAM Select

3.3.13.1 SRAM Installation (U10)

Programming SSD (Floppy)

1. Install the flash in Socket U10.
2. Set the P1&JP4 to SRAM position (The SSD data bank is C800:0)
3. Connect power to the system.
4. Power ON.
5. Press Delete key to display the BIOS Setup menu.
6. Enter CMOS Setup menu. Then choice to CMOS SET UP >ADVANCE CMOS SETUP >SSD FUNCTION set to D000H SEGMENT
7. In the SRAM Disk Simulates field, select FDD that the SRAM disk will act a physical floppy disk. Then, save the setting. (The system will be restart) the screen like below:



8. Press, hold down ctrl_ keys (ctrl & underline) to display the SSD Setup menu.
9. On the screen, use the up or down arrow keys to select a flash type and size. The screen like below:

```

FB2330 SSD BIOS version 1.20 (c) 2000 FabiaTech Corp
SRAM Disk Setting : Disk B:   Unknow ??? ..512K Maximum
Base Port Address : 0078h  Firmware Seg.: D000h  Data Bank Seg.: C800h
DOS Booting Driver : As BIOS Setting M4(U5) Socket Setting: SSD
ESC: Exit   F5: Save & Exit  ← →: Select  ↓ ↑: Modify
Hit<Ctrl, _> to setup Flash disk
    
```

10. Press "F5" to save the setting. The message "Write to FLASH disk (y/n)" prompts.
11. Press "Y" key to write the setting to the Flash disk.
12. The booting from other device. (Like physical HDD or FDD)
13. Use the FORMAT command to format the flash disk in DOS mode. (This time this SSD is B:)
14. Use FORMAT B:/S /C/ U (The S: SYSTEM BOOTING /C: Check /U: UNFORMAT

If format parameterize no " /S " the SSD will be always to device B: that can't booting the system.

Programming SSD (HDD)

1. Install the flash disk in Socket U2, U3, and U12. (Like 29C040A)
2. Set the SW1-1 to off position (The SSD data bank is C800:0)
3. Connect power to the system.
4. Power ON.
5. Press Delete key to display the BIOS Setup menu.
6. Enter the CMOS Setup menu. Then choice to CMOS SET UP >ADVANCE CMOS SETUP
SSD FUNCTION set to D000H SEGMENT
7. In the Flash Disk Simulates field, select HDD that the flash disk will act as a physical hard disk. Then, save the setting. The screen like below:

AMIBIOS SETUP - ADVANCED CMOS SETUP (C)1998 American Megatrends, Inc. All Rights Reserved		
BootUp Num-Lock	Off	Available Options: Disabled ▶ D000H D800H E000H E800H ESC:Exit ↑↓:Sel PgUp/PgDn:Modify F2/F3:Color
Floppy Drive Swap	Disabled	
Floppy Drive Seek	Disabled	
Floppy Access Control	Normal	
HDD Access Control	Normal	
Typematic Rate	Slow	
System Keyboard	Absent	
Primary Display	Absent	
Password Check	Setup	
Wait For 'F1' If Error	Disabled	
Hit 'DEL' Message Display	Disabled	
C000,32k Shadow	Disabled	
C800,32k Shadow	Disabled	
D000,32k Shadow	Disabled	
D800,32k Shadow	Disabled	
E000,32k Shadow	Disabled	
E800,32k Shadow	Disabled	
SRAM Disk	D000H	
SRAM Disk Simulates	HDD	
Close all screen at POST state	Disabled	

8. Press hold down ctrl_ keys (ctrl & underline) to display the SSD Setup menu.
9. On the screen, use the up or down arrow keys to select a flash type and size.
The screen like below:

```

FB2330 SSD BIOS version 1.20 (c) 2000 FabiaTech Corp
SRAM Disk Setting : Disk #80h (C:)   Unknow ??? ..512K Maximum
Base Port Address: 0078h Firmware Seg.: D000h  Data Bank Seg.: C800h
DOS Booting Driver : As BIOS Setting M4(U5) Socket Setting: SSD
ESC: Exit   F5: Save & Exit  ←→: Select  ↓ ↑: Modify
Hit<Ctrl,> to setup Flash disk
    
```

10. Press "F5" to save the setting. The message "Write to FLASH disk (y/n)" prompts.
11. Press "Y" key to write the setting to the Flash disk.
12. The booting from other device. (Like physical HDD or FDD)
13. Use the FDISK command to partition the flash disk in DOS mode. (If system is not physical HDD the SSD is C:)
14. Use FORMAT C:/S /C/ U (The S: SYSTEM BOOTING /C: Check /U: UNFORMAT)
If format parameter no " /S " the SSD will be can't boot the system.

- Note:** 1.If Flash Disk Simulates field select HDD, The flash disk total size must be above to 512KB.
2.An on-board Lithium battery or an external battery pack that could be connected ensures data retention of SRAM to the FB2330.

3.3.13.2 D.O.C. Installation (U10)

- Step 1:** Insert programmed DiskOnChip into Socket U10 setting as DOC.
- Step 2:** Set P1 and JP4 to DOC position.
- Step 3:** Line up and insert the FB2330 card into any free space of your computer.
- Step 4:** The D.O.C. is applied in none HDD equipment. When it is installed, the system can boot directly from D.O.C.

3.3.14 External battery Head (J3)

An external battery pack J3 that could be connected ensures data retention of SRAM




Figure 3-18 EXTERNAL BATTERY CONNECTOR

3.3.15 LED Indicators




Figure 3-19 Onboard LED Indicators

- **Rear Panel LED Indicators: LM1**
LM1 is located on the rear panel with three LED indicators, HDD, Power and LAN.

CHAPTER 4 CRT/LCD FLAT PANEL DISPLAY

This section describes the configuration and installation procedure when using the LCD and CRT displays.

- LCD Flat Panel Displays
 - CRT & LCD Displays
-


4.1 LCD FLAT PANEL DISPLAYS

Using the Flash Memory Writer utility to download the new BIOS file into the ROM chip to configure the BIOS default settings for different types of LCD panels. And then, set your system properly and configure the FB2330 VGA module for the right type of LCD panel you are using.

The samples of LCD models listed on the table are just some of the LCD panel models available in the market that the Chips & Technologies used by FB2330 VGA module can support. If you are using a different LCD panel other than those listed, choose from the panel description column which type of LCD panel you are using.

The FB2330 still needs components to be used for LCD panel. The inverter board provides the control for the brightness and the contrast of the LCD panels while the inverter is the one that supplies the high voltage to drive the LCD panel. Each item will be explained further in the section.

The following shows the block diagram of using FB2330 for LCD display.



The block diagram shows that FB2330 still needs components to be used with a LCD panel. The transfer board (FB4608) provides the control for the brightness and the contrast of the LCD panel while inverter board (FB46xx) is the one that supplies the high voltage to drive the LCD panel. Both FB4608 and FB46xx are available from FabIA Tech with all the necessary cables.

NOTE: Be careful with the pin orientation when installing the connectors and the cables. A wrong connection can easily destroy your LCD panel. The pin 1 of the cable connectors is indicated with a sticker and the pin1 of the ribbon cable is usually with different color.

4.2 CRT & LCD DISPLAY

The FB2330 supports CRT color monitor, STN, Dual-Scan, TFT, monochrome and color panels. It can be connected to create a compact video solution for the industrial environment. 1MB maximum of V-RAM on-boarded allows a maximum CRT resolution of 800X600 with 256 colors and a LCD resolution of 640X480 with 64K colors. For different VGA display modes, your monitor must possess certain characteristics to display the mode you want.

4.2.1 CRT Connector (DB1)

DB1 is a 15-pin connector. The pin assignments for the DB1 connector are as follows:




Figure 4-1 CRT Connector

4.2.2 LCD Connector and Jumper Settings (CN3 & JP1)

CN3 is a 2.0mm 44-pin connector that provides 24-bit LCD interface signals. JP1 is used to select 5V or 3.3V power source of LCD panel.




Figure 4-2 CN3: LCD Connector

CN3	Signal	CN3	Signal	CN3	Signal	CN3	Signal
1	Ground	23	DP15	2	SHFCLK	24	Ground
3	FLM	25	DP16	4	DLP	26	DP17
5	DDE	27	DP18	6	Ground	28	DP19
7	DP0	29	DP20	8	DP1	30	DP21
9	DP2	31	DP22	10	DP3	32	DP23
11	DP4	33	Ground	12	DP5	34	GPO0 (*1)
13	DP6	35	GPO1 (*1)	14	DP7	36	Ground
15	Ground	37	Ground	16	DP8	38	Ground
17	DP9	39	+12V	18	DP10	40	+12V
19	DP11	41	VLCD (*2)	20	DP12	42	VLCD (*2)
21	DP13	43	ENABLK	22	DP14	44	ENAVEE

Table 4-1 LCD Connector Pin Assignments

NOTE: 1. GPO0 and GPO1 pins are TTL outputs. They could be used as LCD back light controls.

2: Different LCD panels use different BIOS and pin connections. If any trouble occurs on connecting the FB2330 to the LCD panels, please contact us.

CHAPTER 5 INSTALLATION

This chapter provides information for you to set up a working system based on the FB2330 CPU board. Carefully read the details of the CPU board's hardware descriptions before installation, especially the jumper settings, switch settings and cable connections. The following topics are covered:

- Overview
 - CD ROM
 - Watchdog Timer
-

5.1 INSTALLATION PROCEDURES

Follow the steps listed below to install the FB2330 system.

- Step 1:** Read the CPU board's hardware description in this manual.
- Step 2:** Set the jumpers.
- Step 3:** Make sure that the power supply connected to your passive CPU board is turned off.
- Step 4:** Connect all necessary cables. Make sure that the FDC, HDC; serial and parallel cables are connected to pin 1 of the related connector.
- Step 5:** Connect the hard disk/floppy disk flat cables from the CPU board to the drives. Connect a power source to each drive.
- Step 6:** Plug the keyboard into the keyboard connector.
- Step 7:** Turn on the power.
- Step 8:** Configure your system with the BIOS Setup program then re-boot your system.
- Step 9:** If the CPU board does not work, turn off the power and read the hardware description carefully again.
- Step 10:** If the CPU board still does not perform properly, return the board to your dealer for immediate service.

5.2 CD ROM

FB2330 provides a CD ROM includes the manual files (a complete manual file and a quick setting guide) and the required utility files. The following will guide you how to install these utility files.

5.2.1 VGA Driver for Win3.1

Step 1: To install the VGA driver, insert the CD ROM into the CD ROM device, and enter DRIVER>FB2330>VGA>65545. If your system is not equipped with a CD ROM device, copy the VGA driver from the CD ROM to a 1.44" diskette.

Step 2: Execute setup.exe file.

Step 3: The screen shows the chip type. Press any key to enter the main menu.

Step 4: There are some items for choice to setup. Please choose the <Windows Version 3.1> item notice the function key defined. Press [ENTER] selected the <All Resolutions>, when this line appears [*] symbol, which means this item is selected. Pressing [End] starts to install.

Step 5: The screen will show the dialog box, demanding the user to type the WIN31's path. The default is C:\WINDOWS.

Step 6: As the setup is completed, the system will generate the message as follows.

Installation is done!

Change to your Windows directory and type SETUP to run the Windows Setup program. Choose one of the new drivers marked by an *. Please refer to the User's Guide to complete the installation.

Step 7: Press the [Esc] key to return to the main menu, and re-press the [Esc] key to return to the DOS mode.

Step 8: In the WIN31, you can find the <Chips CPL> icon located in the {CONTROL PANEL} group.

Step 9: Adjust the <Refresh Rate>, <Cursor Animation>, , <Resolution>, and <Big Cursor>.

Note: In the VGA directory, a readme.txt file is included to provide installation information

5.2.3 LAN Utility

Step 1: To install the LAN utility, insert the CD ROM into the CD ROM device, and enter DRIVER>FB2330>LAN>UM9008. If your system is not equipped with a CD ROM device, copy the LAN VGA driver from the CD ROM to a 1.44" diskette.

Step 2 Execute install.exe file.

5.3 WATCHDOG TIMER

This section describes how to use the Watchdog Timer, disabled, enabled, and trigger.

The FB2330 is equipped with a programmable time-out period watchdog timer. User can use the program to enable the watchdog timer. Once you have enabled the watchdog timer, the program should trigger it every time before it times out. If your program fails to trigger or disable this timer before it times out because of system hang-up, it will generate a reset signal to reset the system or trigger an IRQ signal. The time-out period can be programmed to be 30.5 μ seconds to 512 seconds.




Figure 5-1 Watchdog Block Diagram

5.3.1 Watchdog Timer Setting

The watchdog timer is a circuit that may be used from your program software to detect crashes or hang-ups. The watchdog timer is automatically disabled after reset.

Once you have enabled the watchdog timer, your program must trigger the watchdog timer every time before it times-out. After you trigger the watchdog timer, it will be set to zero and start to count again. If your program fails to trigger the watchdog timer before time-out, it will generate a reset pulse to reset the system or trigger an IRQ signal to tell your program that the watchdog is times out.

Watchdog timer -INDEX 39H, 3AH, and 3BH

```

    3Bh    3Ah    39h
    D7...D0 D7...D0 D7...D0
    Counter [MSB ...LSB]
  
```

For example

```

    INDEX 3Bh 3A 39h
           h
           00h 00h 01h 30.5  $\mu$ sec
  
```

-- -- 02h 61 μ sec
 00h 01h 00h 7.8 m sec
 00h 02h 00h 15.6 m sec
 01h 00h 00h 2 sec
 02h 00h 00h 4 sec
 FFh FFh FFh 512 sec

NOTE: 1. If you program the watchdog to generate IRQ15 signal when it times out, you should initial IRQ15 interrupt vector and enable the second interrupt controller (8259 PIC) in order to enable CPU to process this interrupt. An interrupt service routine is required too.

2. Before you initialize the interrupt vector of IRQ15 and enable the PIC, please enable the watchdog timer previously; otherwise the watchdog timer will generate an interrupt at the time watchdog timer is enabled.

5.3.2 Watchdog Enabled/Disabled - INDEX 37H

Bit 7 Reserved. Please do not set this bit.
 In old version M6117C data sheet, this bit is counter read mode.

Bit 6 0 Disable watchdog timer
 1 Enable watchdog timer

Bit 5-0 Other function.
 Please do not modify these bits.

5.3.3 Select Watchdog Report Signal - INDEX 38H

Bit 7-4 Watchdog timer time out report signal select
 0000 No output signal
 0001 IRQ3 selected
 0010 IRQ4 selected
 0011 IRQ5 selected
 0100 IRQ6 selected
 0101 IRQ7 selected
 0110 IRQ9 selected
 0111 IRQ10 selected
 1000 IRQ11 selected
 1001 IRQ12 selected
 1010 IRQ14 selected
 1011 IRQ15 selected
 1100 NMI selected
 1101 System reset selected
 1110 No output signal
 1111 No output signal

Bit 3-0 Other function.
 Please do not modify these bits.

NOTE: 1. If you program the watchdog to generate IRQ15 signal when it times out, you should initial IRQ15 interrupt vector and enable the second interrupt controller (8259 PIC) in order to enable CPU to process this interrupt. An interrupt service routine is required too. Before you configure the IRQ signals, make sure they are not conflicted with other devices, like Floppy, printer, serial ports, LAN, and PS/2 mouse, etc. Refer to Table 2-2 Interrupt Controller for IRQ reference.

2. Before you initialize the interrupt vector of IRQ15 and enable the PIC, please enable the watchdog timer previously; otherwise the watchdog timer will generate an

interrupt at the time watchdog timer is enabled. If you want to generate IRQ15 signal to warn your program when watchdog times out, the following table listed the relation of timer factors between time-out period. And if you use the IRQ15 signal to warn your program when watchdog timer out, please enter the BIOS Setup the <Peripheral Setup> menu, the <OnBoard PCI IDE> and <IDE Prefetch> these two items must set to *Primary*.

5.3.4 Timeout Status & Reset Watchdog - INDEX 3CH

Bit 7 0 Timer timeout not happened
 1 Timer timeout happened
 Read only.

Bit 5 Write this bit "1" to reset timer
 The value on this bit has no meaning.

Bit 6 Other function.

Bit 4-0 Please do not modify these bits.

5.3.5 Programming Watchdog - Basic Operation

If we would like to access M6117C configuration register, we need to unlock register at first and lock it after finishing operation.

➤ Unlock Configuration Register

```
mov  al, 013h
out  22h, al
nop
nop
mov  al, 0c5h
out  23h, al
nop
nop
```

➤ Lock Configuration Register

```
mov  al, 013h
out  22h, al
nop
nop
mov  al, 000h
out  23h, al
nop
nop
```

➤ Read the Value at Configuration Register

For example, read INDEX 3Ch:
 Unlock configuration register

```
mov  al, 03ch
out  22h, al
nop
nop
in   al, 23h
nop
```

nop

push ax

Lock configuration register

pop ax ; AL - result

➔ **Write Data to Configuration Register**

For example, write 0FFh to INDEX 3Bh:

Unlock configuration register

mov al, 03bh

out 22h, al

nop

nop

mov al, 0ffh

out 23h, al

nop

nop

Lock configuration register

5.4 PROGRAMMING RS-485

The majority communicative operation of the RS-485 is in the same of the RS-232. When the RS-485 precedes the transmission, which needs control the TXC signal, and the installing, steps are as follows:

Step 1: Enable TXC

Step 2: Send out data

Step 3: Waiting for data empty

Step 4: Disable TXC

NOTE: Please refer to the section of the "Serial Ports" in the Chapter "System Controllers" for the detail description of the COM port's register.

➡ Initialize COM port

Step 1: Initialize COM port in the receiver interrupt mode, and /or transmitter interrupt mode. (All of the communication protocol buses of the RS-485 are in the same.)

Step 2: Disable TXC (transmitter control), the bit 0 of the address of offset+4 just sets "0".

NOTE: Control the FB2330 CPU card's DTR signal to the RS-485' s TXC communication.

➡ Send out one character (Transmit)

Step 1: Enable TXC signal, and the bit 0 of the address of offset+4 just sets "1".

Step 2: Send out the data. (Write this character to the offset+0 of the current COM port address)

Step 3: Wait for the buffer's data empty. Check transmitter holding register (THRE, bit 5 of the address of offset+5), and transmitter shift register (TSRE, bit 6 of the address of offset+5) are all sets must be "0".

Step 4: Disabled TXC signal, and the bit 0 of the address of offset+4 sets "0"

➡ Send out one block data (Transmit – the data more than two characters)

Step 1: Enable TXC signal, and the bit 0 of the address of offset+4 just sets "1".

Step 2: Send out the data. (Write all data to the offset+0 of the current COM port address)

Step 3: Wait for the buffer's data empty. Check transmitter holding register (THRE, bit 5 of the address of offset+5), and transmitter shift register (TSRE, bit 6 of the address of offset+5) are all sets must be "0".

Step 4: Disabled TXC signal, and the bit 0 of the address of offset+4 sets "0"

➡ Receive data

The RS-485's operation of receiving data is in the same of the RS-232's.

➔ Basic Language Example

a. Initial 86C450 UART

```
10 OPEN "COM1:9600,m,8,1" AS #1 LEN=1
20 REM Reset DTR
30 OUT &H3FC, (INP(%H3FC) AND &HFA)
40 RETURN
```

b. Send out one character to COM1

```
10 REM Enable transmitter by setting DTR ON
20 OUT &H3FC, (INP(&H3FC) OR &H01)
30 REM Send out one character
40 PRINT #1, OUTCHR$
50 REM Check transmitter holding register and shift register
60 IF ((INP(&H3FD) AND &H60) >0) THEN 60
70 REM Disable transmitter by resetting DTR
80 OUT &H3FC, (INP(&H3FC) AND &HEF)
90 RETURN
```

c. Receive one character from COM1

```
10 REM Check COM1: receiver buffer
20 IF LOF(1)<256 THEN 70
30 REM Receiver buffer is empty
40 INPSTR$=""
50 RETURN
60 REM Read one character from COM1: buffer
70 INPSTR$=INPUT$(1,#1)
80 RETURN
```

NOTE: The example of the above program is based on COM1 (I/O Address 3F8h). The RS-485 of the FB2330 uses COM4. If you want to program it, please refer to the BIOS Setup for COM4 address setup.

CHAPTER 6 BIOS SETUP

This chapter describes the FB2330 BIOS menu displays and explains how to perform common tasks, and presents detailed explanations of the elements found in each of the BIOS menus. The following topics are covered:

- BIOS Setup Overview
- Standard CMOS Setup
- Advanced CMOS Setup
- Advanced Chipset Setup
- Peripheral Setup
- Auto-Detect Hard Disks
- Password Setting
- Load Default Setting
- BIOS Exit

6.1 BIOS SETUP OVERVIEW

BIOS (Basic Input Output System) is a program used to initialize and set up the I/O devices of the computer, which includes the ISA bus and connected devices such as the video display, diskette drive, and the keyboard.

The BIOS provides a menu-driven interface to the console subsystem. The console subsystem contains special software, called firmware that interacts directly with the hardware components and facilitates interaction between the system hardware and the operating system.

The BIOS Default Values ensure that the system will function at its normal capability. In the worst situation the user may have corrupted the original settings set by the manufacturer. After the computer turned on, the BIOS will perform a diagnostics of the system is being tested. Press the [Del] key to enter the BIOS Setup program, and then the main menu will show on the screen.

The BIOS Setup main menu includes some options. Use the [Up/Down] arrow key to highlight the option that you wish to modify, and then press the [Enter] key to assure the option and configure the functions.




Figure 6-1 BIOS Main Menu

- CAUTION:** 1. The factory-default setting in the FB2330 BIOS is used to the <Auto Configuration with Optimal Settings>, we recommend using the BIOS default setting, unless you are very familiar with the setting function, or you can contact the technical support engineer.
2. If the BIOS losses setting, the CMOS will detect the <Auto Configuration with Fail Safe Settings> to boot the operation system, this option will reduce the performance of the system. It is recommended to choose the <Auto Configuration with Optimal Setting> in the main menu. The option is best-case values that should optimize system performance.
3. The BIOS settings are described in detail in this section.

6.2 STANDARD CMOS SETUP

The <Standard CMOS Setup> option allows you to record some basic system hardware configuration, set the system clock and error handling. If the CPU board is already installed in a working system, you will not need to select this option anymore.

AMIBIOS SETUP - STANDARD CMOS SETUP									
(C)1998 American Megatrends, Inc. All Rights Reserved									
Date (mm/dd/yyyy): Thu Dec 14, 2000					0 KB				
Time (hh/mm/ss) : 15:07:13					0 MB				
Floppy Drive A: 1.44 MB 3½									
Floppy Drive B: Not Installed									
	Type	Size	Cyln	Head	WPcom	Sec	LBA Mode	Blk Mode	PIO 32Bit Mode
Pri Master	: Auto								Off
Pri Slave	: Auto								Off
Boot Sector Virus Protection					Disabled				
1-46	: Predefined types						ESC:Exit ↑↓:Sel		
USER	: Enter parameters manually						PgUp/PgDn:Modify		
AUTO	: Set parameters automatically on each boot						F2/F3:Color		
CDROM	: Use for ATAPI CDROM drives								
FLOPTICAL	: Use for ATAPI FLOPTICAL drives								
Or press ENTER to autodetect									

Figure 6-2 Standard CMOS Setup

Date & Time Setup

Highlight the <Date> field and then press the [Page Up] / [Page Down] or [+]/[-] keys to set the current date. Follow the month, day and year format.

Highlight the <Time> field and then press the [Page Up] / [Page Down] or [+]/[-] keys to set the current date. Follow the hour, minute and second format.

The user can bypass the date and time prompts by creating an AUTOEXEC.BAT file. For information on how to create this file, please refer to the MS-DOS manual.

Floppy Setup

The <Standard CMOS Setup> option records the types of floppy disk drives installed in the system.

To enter the configuration value for a particular drive, highlight its corresponding field and then select the drive type using the left- or right-arrow key.

Hard Disk Setup

The BIOS supports various types for user settings. The BIOS supports <Pri Master>, <Pri Slave>, <Sec Master> and <Sec Slave> so the user can install up to four hard disks. For the master and slave jumpers, please refer to the hard disk's installation descriptions and the hard disk jumper settings.

You can select <AUTO> under the <TYPE> and <MODE> fields. This will enable auto detection of your IDE drives during bootup. This will allow you to change your hard drives (with the power off) and then power on without having to reconfigure your hard drive type. If you use older hard disk drives, which do not support this feature, then you must configure the hard disk drive in the standard method as described above by the <USER> option.

Boot Sector Virus Protection

This option protects the boot sector and partition table of your hard disk against accidental modifications. Any attempt to write to them will cause the system to halt and display a warning message. If this occurs, you can either allow the operation to continue or use a bootable virus-free floppy disk to reboot and investigate your system. The default setting is **<Disabled>**. This setting is recommended because it conflicts with new operating systems. Installation of new operating system requires that you disable this to prevent write errors.

6.3 ADVANCED CMOS SETUP

The <Advanced CMOS SETUP> option consists of configuration entries that allow you to improve your system performance, or let you set up some system features according to your preference. Some entries here are required by the CPU board's design to remain in their default settings.

AMIBIOS SETUP - ADVANCED CMOS SETUP		
(C)1998 American Megatrends, Inc. All Rights Reserved		
1st Boot Device	IDE-0	Available Options: Disabled ▶ IDE-0 IDE-1 IDE-2 IDE-3 Floppy ARMD-FDD ARMD-HDD CDROM SCSI NETWORK ESC:Exit ↑↓:Sel PgUp/PgDn:Modify F2/F3:Color
2nd Boot Device	Floppy	
3rd Boot Device	CDROM	
Quick Boot	Enabled	
BootUp Num-Lock	On	
Floppy Drive Swap	Disabled	
Floppy Drive Seek	Disabled	
Floppy Access Control	Normal	
HDD Access Control	Normal	
PS/2 Mouse Support	Disabled	
Typeomatic Rate	Fast	
System Keyboard	Absent	
Primary Display	Absent	
Password Check	Setup	
Wait For 'F1' If Error	Disabled	
Hit 'DEL' Message Display	Enabled	
C000,32k Shadow	Enabled	
C800,32k Shadow	Disabled	
D000,32k Shadow	Disabled	
D800,32k Shadow	Disabled	
E000,32k Shadow	Disabled	
E800,32k Shadow	Disabled	
SRAM Disk	Disabled	
SRAM Disk Simulates	HDD	
Close all screen at POST state	Disabled	

Figure 6-3 Advanced CMOS Setup

1st-3rd Boot Device

These fields determine where the system attempts to look for the boot drive priority for an operating system. The default procedure is to check the hard disk, and then the floppy drive, and last the CDROM.

Available Options: Disabled, IDE0-1, IDE-2, IDE-3, Floppy, ARMD-FDD, ARMD-HDD, CDROM, and SCSI, Network

Default setting: IDE-0 for 1st Boot device; Floppy for 2nd Boot Device; CDROM for 3rd Boot Device

S.M.A.R.T for Hard Disks

This field is used to activate the S.M.A.R.T (System Management and Reporting Technologies) function for S.M.A.R.T HDD drives. This function requires an application that can give S.M.A.R.T message.

Available Options: Disabled, Enabled

Default: Disabled

Quick Boot

This field is used to activate the quick boot function of the system. When set to Enabled,

1. BIOS will not wait for up to 40 seconds if a Ready signal is not received from the IDE drive, and will not configure its drive.
2. BIOS will not wait for 0.5 seconds after sending a RESET signal to the IDE drive.

3. You can not run BIOS Setup at system boot since there is no delay for the Hit, Del. To run Setup message.

Available Options: Disabled, Enabled

Default setting: Enabled

BootUp Num-Lock

This field is used to activate the Num Lock function upon system boot. If the setting is on, after a boot, the Num Lock light is lit, and user can use the number key.

Available Options: On, Off

Default setting: On

Floppy Drive Swap

The field reverses the drive letter assignments of your floppy disk drives in the Swap A, B setting, otherwise leave on the default setting of **Disabled** (No Swap). This works separately from the BIOS Features floppy disk swap feature. It is functionally the same as physically interchanging the connectors of the floppy disk drives. When the function's setting is **<Enabled>**, the BIOS swapped floppy drive assignments so that Drive A becomes Drive B, and Drive B becomes Drive A under DOS.

Available Options: Disabled, Enabled

Default setting: Disabled

Floppy Drive Seek

This field is used to set if the BIOS will seek the floppy <A> drive upon boot.

Available Options: Disabled, Enabled

Default setting: Disabled

Floppy Access Control

This field specifies the read/write access when booting from a floppy drive.

Available Options: Normal, Read-only

Default setting: Normal

HDD Access Control

This field specifies the read/write access when booting from a HDD drive.

Available Options: Normal, Read-only

Default setting: Normal

PS/2 Mouse Support

The PS/2 mouse function is optional. Before you configure this field, make sure your FB2330 supports this feature. The setting of **Enabled** allows the system to detect a PS/2 mouse on bootup. If detected, IRQ12 will be used for the PS/2 mouse. IRQ 12 will be reserved for expansion cards if a PS/2 mouse is not detected. **Disabled** will reserve IRQ12 for expansion cards and therefore the PS/2 mouse will not function.

Available Options: Disabled, Enabled

Default setting: Disabled

Typematic Rate

This function specifies the keystroke repeat rate when a key is pressed and held down.

Available Options: Fast, Slow

Default setting: Fast

System Keyboard

This field specifies if an error message should be prompted when a keyboard is not attached.

Available Options: Absent, Present

Default setting: Absent

Primary Display

The field specifies the type of monitor installed in the system.

Available Options: Absent, Normal

Default setting: Absent

Password Check

This field enables password checking every time the computer is powered on or every time the BIOS Setup is executed. If **Always** is chosen, a user password prompt appears every time and the BIOS Setup Program executes and the computer is turned on. If **Setup** is chosen, the password prompt appears if the BIOS executed.

Available Options: Setup, Always

Default setting: Setup

Wait for 'F1' If Error

AMIBIOS POST error messages are followed by:

Press <F1> to continue

If this field is set to **Disabled**, the AMIBIOS does not wait for you to press the <F1> key after an error message.

Available Options: Disabled, Enabled

Default setting: Disabled

Hit 'DEL' Message Display

Set this field to **Disabled** to prevent the message as follows:

Hit 'DEL' if you want to run setup

It will prevent the message from appearing on the first BIOS screen when the computer boots.

Available Options: Disabled, Enabled

Default setting: Enabled

C000, 32k Shadow - E800, 32k shadow

These fields control the location of the contents of the 32KB of ROM beginning at the specified memory location. If no adapter ROM is using the named ROM area, this area is made available to the local bus. The settings are:

1. **Disabled:** The video ROM is not copied to RAM. The contents of the video ROM cannot be read from or written to cache memory.
2. **Enabled:** The contents of C000h - C7FFFh are written to the same address in system memory (RAM) for faster execution.
3. **Cached:** The contents of the named ROM area are written to the same address in system memory (RAM) for faster execution, if an adapter ROM will be using the named ROM area. Also, the contents of the RAM area can be read from and written to cache memory.

Available Options: Disabled, Enabled, And Cached

Default setting: Disabled

SRAM DISK

These fields control the location of the contents of the solid-state disk beginning.

Available Options: Disabled, D000, D800, E000, and E800.

Default setting: Disabled

SRAM Simulates

When HDD is selected, the system will boot from the SRAM as if it is a hard disk drive (C). When FDD is selected, the system will boot from the SRAM as if it is a floppy disk drive (a:).

Available Options: HDD, FDD

Default setting: HDD

Close all screen at post

Upon power on, the system will skip POST, and enter the OS in five seconds. If this function is enabled, also configure the following fields to the appointed values.

Hit 'Del' Message Display: Disabled

Wait For 'F1' If Error: Disabled

System Keyboard: Absent

Primary Display: Absent

Hard Disk Display: Disabled

Available Options: Disabled, Enabled

Default setting: Disabled

6.4 ADVANCED CHIPSET SETUP

This option controls the configuration of the board's chipset. Control keys for this screen are the same as for the previous screen.




Figure 6-4 Advanced Chipset Setup

AT Bus Clock

This field sets the polling clock speed of ISA Bus (PC/104).

Available Options: 14.318/2, PCLK/5, PCLK/6, PCLK/8, PCLK/12

Default setting: 14.318/2

- NOTE:**
1. PCLK means the CPU inputs clock.
 2. User is recommended to use setting at the range of 8MHz to 10MHz.

Slow Refresh

This field sets the DRAM refresh cycle time.

Available Options: 15 us, 60 us, and 120 us

Default setting: 60 us

RAS Precharge Time

This field specifies the length of the RAS precharge part of the DRAM access cycle when EDO DRAM is installed.

Available Options: 1.5- 3.5 T

Default setting: 1.5T

RAS Active Time Insert Wait

This field specifies the RAS Active Time Insert Wait function.

Available Options: Disabled, Enabled

Default setting: Disabled

CAS Precharge Time Insert Wait

This field specifies the DRAM CAS precharge time.

Available Options: Disabled, Enabled

Default setting: Disabled

Memory Write Insert Wait

This field specifies the Memory Write Insert Wait function.

Available Options: Disabled, Enabled

Default setting: Disabled

ISA I/O High Speed

The field specifies the ISA I/O High Speed function.

Available Options: Disabled, Enabled

Default setting: Enabled

ISA Memory High Speed

This field specifies the ISA Memory High Speed function

Available Options: Disabled, Enabled

Default setting: Enabled

I/O Recovery

If I/O Recovery Feature field is enabled, the BIOS insert a delay time between two I/O commands. The delay time is defined in I/O Recovery Period field.

Available Options: Disable, Enable

Default setting: Disable

I/O Recovery Period

This specifies the I/O recovery delay time.

Available Options: 0 – 3.5 us

Default setting: 1.5 us

16Bit ISA Insert Wait

This field specifies the 16bit ISA Insert Wait function.

Available Options: Disable, Enable

Default setting: Disable

Watch Dog Timer Output Control

This function is to enable or disable the Watchdog timer function.

Available Options: Disabled, 30, 45, 60, 75, 90, 105 and 120 sec

Default setting: Disabled

Watch Dog Timeout Trigger Signal

This field can be configured.

This function is to select IRQ or RESET for the Watchdog different function.

Available Options: IRQ3, IRQ4, IRQ9, IR10, IRQ11, IRQ12, IRQ15 and RESET

Default setting: RESET

6.5 PERIPHERAL SETUP

This section is used to configure peripheral features.

AMIBIOS SETUP - PERIPHERAL SETUP (C)1998 American Megatrends, Inc. All Rights Reserved		
OnBoard IDE	Enabled	Available Options: ▶ 5 7
OnBoard FDC	Enabled	
OnBoard Serial Port1	3F8h	
OnBoard Serial Port1 IRQ	4	
OnBoard Serial Port2	2F8h	
OnBoard Serial Port2 IRQ	3	
OnBoard Serial Port3	3E8h	
OnBoard Serial Port3 IRQ	11	
OnBoard Serial Port4	2E8h	
OnBoard Serial Port4 IRQ	9	
OnBoard Parallel Port1	378	
Parallel Port1 Mode	Normal	
EPP Version	N/A	
Parallel Port1 IRQ	7	
Parallel Port1 DMA Channel	N/A	
OnBoard Parallel Port2	278	
Parallel Port2 Mode	Normal	
EPP Version	N/A	
Parallel Port2 IRQ	5	ESC:Exit ↑:Sel
Parallel Port2 DMA Channel	N/A	PgUp/PgDn:Modify F2/F3:Color

Figure 6-5 Peripheral Setup

Hard Disk Delay

If this field is set to **Disabled** and the system BIOS executes too fast, the result is the BIOS can't find the hard disk drive.

Available Options: Disabled, 3 Sec, 5 Sec, 10 Sec, and 15 Sec

Default setting: 3 Sec

OnBoard IDE

This field specifies the onboard primary IDE controller channels that will be used.

Available Options: Disabled, Enabled

Default setting: Enabled

OnBoard FDC

This field enables the floppy drive controller on the FB2330.

Available Options: Disabled, Enabled

Default setting: Enabled

OnBoard Serial Port 1 - 4

These fields select the I/O port address for each Serial port. Refer to Table 2-2.

Available Options: Disabled, 2F8H, 3F8H, 2E8H, 3E8H

Default setting: 3F8H, 2F8H, 3E8H respectively

OnBoard Serial Port 1- 2 IRQ

These fields select the IRQ for each serial port.

Available Options: 3, 4, 5, and 9

Default setting: IRQ4 for Port 1; IRQ3 for Port 2

OnBoard Serial Port 3- 4 IRQ

These fields select the IRQ for each serial port.

Available Options: 3, 4, 5, 9, 10, 11, and 12

Default setting: IRQ11 for Port 3; IRQ9 for Port 4

OnBoard Parallel Port 1 & 2

This field selects the I/O port address for parallel port. Refer to Table 2-2.

Available Options: Auto, Disabled, 378, 278 and 3BCH

Default setting: 378H for Port 1; 278H for Port 2

Parallel Port Mode/ Parallel Port 2 Mode

This field specifies the parallel port mode. ECP and EPP are both bi-directional data transfer schemes that adhere to the IEEE P1284 specifications.

Available Options: Normal, EPP, and ECP

Default setting: Normal (Port 1 & Port 2)

EPP Version

This field specifies the EPP for the Parallel Port/Port2 Mode specification version used in the system and is not configurable.

Parallel Port IRQ/ Parallel Port 2 IRQ

This field specifies the IRQ for the parallel port/port 2.

Available Options: 5, 7

Default setting: IRQ7 for Parallel Port; IRQ5 for Parallel Port 2

Parallel Port DMA Channel/ Parallel Port2 DMA Channel

These two fields are for monitor only and cannot be configured.

6.6 AUTO-DETECT HARD DISKS

This field detects the parameters of an IDE hard disk drive, and automatically enters them into the Standard CMOS Setup screen.

6.7 PASSWORD SETTING

This BIOS Setup has an optional password feature. The system can be configured so that all users must enter a password every time the system boots or when BIOS Setup is executed. User can set either a Supervisor password or a User password.

6.7.1 Setting Password

Select the appropriate password icon (Supervisor or User) from the Security section of the BIOS Setup main menu. Enter the password and press [Enter]. The screen does not display the characters entered. After the new password is entered, retype the new password as prompted and press [Enter].

If the password confirmation is incorrect, an error message appears. If the new password is entered without error, press [Esc] to return to the BIOS Main Menu. The password is stored in CMOS RAM after BIOS completes. The next time the system boots, you are prompted for the password function is present and is enabled.

Enter new supervisor password:




Figure 6-6 Enter New Super User Password

6.7.2 Password Checking

The password check option is enabled in Advanced Setup by choosing either **Always** (the password prompt appears every time the system is powered on) or **Setup** (the password prompt appears only when BIOS is run). The password is stored in CMOS RAM. User can enter a password by typing on the keyboard. As user select Supervisor or User. The BIOS prompts for a password, user must set the Supervisor password before user can set the User password. Enter 1-6 character as password. The password does not appear on the screen when typed. Make sure you write it down.

6.8 LOAD DEFAULT SETTINGS

It permits user to select a group of setting for all BIOS Setup options. Not only can you use these fields to quickly set system configuration parameters, you can choose a group of settings that have a better chance of working when the system is having configuration related problems.

6.8.1 Auto Configuration with Optimal Settings

User can load the optimal default settings for the BIOS. The optimal default settings are best-case values that should optimize system performance. If CMOS RAM is corrupted, the optimal settings are loaded automatically.

Load high performance settings (Y/N)?



Figure 6-7 Load High Performance Setting

6.8.2 Auto Configuration with Fail Safe Settings

User can load the Fail-Safe BIOS Setup option settings by selecting the Fail-Safe item from the Default section of the BIOS Setup main menu.

The Fail-Safe settings provide far from optimal system performance, but are the most stable settings. Use this option as a diagnostic aid if the system is behaving erratically.

Load failsafe settings (Y/N)?



Figure 6-8 Load Failsafe Setting

6.9 BIOS EXIT

It is used to exit the BIOS main menu in two types situation. After making your changes, you can either save them or exit the BIOS menu and without saving the new values.

6.9.1 Save Settings and Exit

It is used to save the modified values set in the <Standard CMOS Setup>, <Advanced CMOS Setup>, <Advanced Chipset Setup> and the new password (if it has been changed) will be stored in the CMOS. The CMOS checksum is calculated and written into the CMOS.

As you select this function, the following message will appear at the center of the screen to assist you to save data to CMOS and Exit the Setup.

Save current settings and exit (Y/N)?




Figure 6-9 Save Current Settings and Exit

6.9.2 Exit Without Saving

When you select this option, the following message will appear at the center of the screen to help to abandon all Data and Exit Setup.

Quit without saving (Y/N)?




Figure 6-10 Quit Without Saving

6.10 BIOS UPDATE

The BIOS program instructions are contained within computer chips called FLASH ROMs that are located on your system board. The chips can be electronically reprogrammed, allowing you to upgrade your BIOS firmware without removing and installing chips.

The FB2330 provides FLASH BIOS update function for you to easily upgrade newer BIOS version. Please follow the operating steps for updating new BIOS:

Step 1: Turn on your system and skip detecting the CONFIG.SYS and AUTOEXEC.BAT files. Keep your system in the real mode.

Step 2: Insert the FLASH BIOS diskette into the floppy disk drive.

Step 3: In the MS-DOS mode, you can type the AMIFLASH program.

```
A:\>AMIFLASH
```

Step 4: The screen will show the message as follows:

Enter the BIOS File name from which Flash EPROM will be programmed. The File name must end with a <ENTER> or press <ESC> to exit.

Step 5: Enter the file name to the box of <Enter File Name>. And the box of <Message> will show the notice as follows. The bottom of this window always shows the gray statement.

Flash EPROM Programming is going to start. System will not be usable until Programming of Flash EPROM is successfully complete. In case of any error, existing Flash EPROM must be replaced by new program Flash EPROM.

Step 6: As the gray statement, press the <Y> key to updating the new BIOS. And then the <Message> box will show the <Programming Flash EPROM>, and the gray statement shows <Please Wait>.

Step 7: The BIOS update is successful, the message will show <Flash Update Completed - Pass>.


- NOTE:**
1. If the system doesn't detect the boot procedure after power on, please press the [F5] key immediately. The system will pass the CONFIG.SYS and AUTOEXEC.BAT files.
 2. The BIOS flash disk is not a standard accessory. Now the onboard BIOS are the newest BIOS. If user needs to add some functions in the future, please contact our technical supporting engineers, they will provide the newest BIOS for updating.
 3. Use the file AMIFLASH.EXE from the attached CD ROM's file. It not, uses Version 6.31.

APPENDIX


A. SPECIFICATIONS

CPU & Chipset:	ALI M6117, 33/40 MHz under 5V power supply
Bus Interface:	PC/104 bus
DRAM:	8MB EDO RAM on-board
CRT/LCD Display:	512K VRAM (standard); 1 MB VRAM optional
HDC:	Two IDE type hard disk drives
FDC:	Two 5.25" or 3.5" floppy disk drives
Serial Port:	4 full RS-232C ports with phone-jack connectors, RS-485 available
Parallel Port:	2 bi-directional centronics type parallel port
Keyboard:	PC/AT compatible keyboard with 6-pin mini-din connector
Real Time Clock:	BQ3287MT or compatible chips
BIOS:	Legal AMI Flashed system BIOS
Watchdog:	Programmable Watchdog timer
Solid State Disk:	1 socket for up to 288 MB DiskOnChip or 512 KB SRAM disk
Ethernet:	NE2000 compatible, RJ-45 edge connector or BNC connector (Option)
Buzzer	One buzzer on board
LED Indicator:	Power LED, LAN LED, and HDD LED
Power Connector:	One 4-pin and one 8-pin (2.5mm) optional power connector
Power Req.:	+5V, 2.0A maximum
PC Board:	6 layers
Dimensions:	145 mmX102mm
Form factor:	3.5" diskette form factor
Safety:	EMI considered on every output signals
Other Optional features:	E2KEY function for safe CMOS data keeping; DS2401 silicon serial number and PS/2 mouse

B1. PLACEMENT



B2. DIMENSIONS



Unit: mm

C1. SRAM MEMORY BANKS

This provides the information about how to access the memory on the FB2330. The FB2330 hardware divides every 8K bytes of memory into a memory bank. To access the data in the memory, you have to assign a bank number. The memory bank number starts from zero. The last memory bank number depends on the size of the memory chip used on the FB2330. For example, if you use the 128K bytes memory chip, the bank number would be in the range of 0 to 15.

If a SRAM is installed to the system, the BIOS CMOS SETUP is determined by select 68h or 78h.

AMIBIOS SETUP - ADVANCED CMOS SETUP (C)1998 American Megatrends, Inc. All Rights Reserved		
BootUp Num-Lock	Off	Available Options: HDD ▶ FDD
Floppy Drive Swap	Disabled	
Floppy Drive Seek	Disabled	
Floppy Access Control	Normal	
HDD Access Control	Normal	
Typematic Rate	Slow	
System Keyboard	Absent	
Primary Display	Absent	
Password Check	Setup	
Wait For 'F1' If Error	Disabled	
Hit 'DEL' Message Display	Disabled	
C000,32k Shadow	Disabled	
C800,32k Shadow	Disabled	
D000,32k Shadow	Disabled	
D800,32k Shadow	Disabled	
E000,32k Shadow	Disabled	
E800,32k Shadow	Disabled	
SRAM Disk	D000H	ESC:Exit F1:Sel PgUp/PgDn:Modify F2/F3:Color
SRAM Disk Simulates	FDD	
Close all screen at POST state	Disabled	

The I/O port address of the bank select base port 78h or 68h, the following is the format of the chip select and bank enable.

Register	I/O Port	D5	D4	D3	D2	D1	D0
Bank select	Base 0	A5	A4	A3	A2	A1	A0

Where:

A5-A0 Bank select bits, A0 is the LSB

For different types of memory, A0 to A5 have different explanations. These bits are used to select the bank number.

Memory	A5	A4	A3	A2	A1	A0
128KB SRAM	0	1	BS3	BS2	BS1	BS0
512KB SRAM	BS5	BS4	BS3	BS2	BS1	BS0

NOTE: BS0 to BS5 are the memory bank select bits. For example, 128KB memory has sixteen 8K-byte banks; so 4 bits (BS0 to BS3) are needed.

Example: Select the 10th bank of the U7 on the FB2330. Using CXK581000P/M (128K*8), and the base port is &H78.

```
100 base_port=&H78
110 OUT base_port,&H19
```

SRAM TYPE SUPPORTED

The following list contains SRAMs supported by the FB2330:

AKM	AKM628128	(128KX8, 1M bits)
HITACHI	HM628128	(128KX8, 1M bits)
NEC	UPD431000A	(128KX8, 1M bits)
SONY	CXK581000P/M	(128KX8, 1M bits)
HITACHI	HM628512	(512KX8, 4M bits)
NEC	UPD434000	(512KX8, 4M bits)
SONY	CXK584000P/M	(512KX8, 4M bits)

D1. PROGRAMMING GPO0 (1) - BASIC OPERATION

If we would like to use I/O control GPO0 & GPO1 with backlight board, that must be program it. The control port is 72h or 7Ah

For example,

```
mov dx, 72h           ;Base Port 72h
mov al, 30h          ;BIT 4 (GPIO 0) ,BIT 5 (GPIO1)
out dx, al           ;Output
nop
in al, dx            ;Input
```